

PACKARD MOTOR CAR COMPANY

DETROIT MICHIGAN

November 29, 1926

To PACKARD DISTRIBUTERS AND DEALERS

Subject INSTALLATION OF PACKARD KELCH HEATERS

TO BE NOTED AND INITIALED BY	
<i>TKW</i>	
<i>J.D.W.</i>	

Gentlemen:

The mechanics in the New York Accessory Department have developed an easier way to attach Kelch Heaters to the improved Sixes and Eights 426-433 and 336-343.

The procedure is as follows:

Measure 23 $\frac{3}{4}$ inches from cast iron front face of muffler along exhaust pipe - cut exhaust pipe off at this point. Then remove bolts holding muffler to frame, also bracket holding end of exhaust pipe to frame. Drop muffler, remove cut piece of exhaust pipe - set heater unit into place - attach front end of heater unit to exhaust pipe first - then attach rear end of heater unit to front end of muffler - replace muffler to frame and tighten all bolts and clamps.

The above procedure eliminates the necessity of removing exhaust pipe from car, thereby saving a great deal of time formerly needed in disconnecting exhaust pipe to manifold bolts, etc.

Time saved - approximately three quarters of an hour.

Please bring this to the attention of your shop men.

Yours very truly,

PACKARD MOTOR CAR COMPANY

J. D. Wilson

J. D. Wilson
Accessory Manager

JDW:ND
(e) 1500