

REFER TO THIS LETTER BY NUMBER

PACKARD MOTOR CAR COMPANY**DETROIT MICHIGAN**

October 18, 1929

To **PACKARD DISTRIBUTERS AND DEALERS**Subject **HEATER INSTALLATION TOOLS**

TO BE NOTED AND INITIALED BY

Gentlemen:

You can save a great deal of time in the installation of Packard-Kelch and Packard-Francisco heaters if you will use the special tools recommended by the factory Special Tool Department for cutting holes in the floor boards or dash.

The complete set of tools consisting of the mandrel and three cutters listed below are carried in the Special Tool Department at the factory under S.T.-760 - Dash Cutter Set for Heaters and may be purchased for \$4.90 net. The same tools may also be purchased from any Black and Decker distributor.

The Black and Decker individual numbers of the tools are listed below along with our numbers of these tools.

	Packard No.	Black & Decker Number
1 - Mandrel	ST-1358	00904
1 - 2-3/8 Hole Saw (To cut hole in front compartment for Francisco and Kelch Heater front compartment registers)	ST-1339	00921
1 - 2-1/16 Hole Saw (To cut hole in front compartment toe board for air intake of Kelch Heater)	ST-1375	00919
1 - 3-1/4 Hole Saw (To cut hole in rear compartment floor board for rear Kelch Heater register)	ST-1376	00929

NOTE: The rear compartment Francisco Heater register requires a rectangular hole - hence, there is no cutter.

Yours very truly,
PACKARD MOTOR CAR COMPANY



J. D. Wilson
General Accessory Manager

JDW:B
(d) 2300
Dealers' T.L. No. 70