

Change Bulletin No. 2

Packard Eight—Service Parts List

JULY 1925

PackardInfo.com

Packard Motor Car Company

Detroit, Michigan, U. S. A.

CHANGE BULLETIN NO. 2

PACKARD EIGHT—SERVICE PARTS LIST

JULY 1925

Page No.	Piece No.	Change	No. Required			
			136	143	236	243
2	130728	Battery anchor bolt—Change piece number to read 130591.				
4	117787	Bonnet handle—Change piece number to read 61041 and add note (Black enamel).				
	137455	Bonnet handle (nickel plate)—Add.....			2	2
7	114147	Clutch shaft bushing—front—Add note (Prior to motor No. 211502).				
	136995	Clutch shaft bushing—front (After motor No. 211501)—Add.....			1	1
8	127978	Differential driving gear and pinion assembly—4-7/10 to 1—Remove.				
	137507	Differential driving gear and pinion assembly 4 ⁷ / ₁₀ to 1—Add.....	1	1	1	1
		Add note (Use only on 234-246) to the following:				
9	126652	Differential driving pinion bearing front nut.				
	118246	Differential driving pinion bearing sleeve lock.				
		Add the following with note (Not used on 234-246):				
9	136794	Differential driving pinion bearing front nut 4 ⁷ / ₁₀ to 1.....			1	1
	136793	Differential driving pinion bearing sleeve lock 4 ⁷ / ₁₀ to 1.....			1	1
9	127410	Differential driving pinion bearing sleeve and cups assembly—Change piece number to read 134292.				
13	130725	Motor starter motor—Change piece number to read 138083.				
	121070	Ignition coil—Change piece number to read 137120.				
16	130725	Motor starter motor—Change piece number to read 138083.				
	121070	Ignition coil—Change piece number to read 137120.				
		Add the following:				
19	7705	Ignition coil screw.....			4	4
	5500	Ignition coil screw lock washer.....			4	4
30	126119	Steering cross tube ball socket casing—Change piece number to read 137118.				
	126150	Steering cross tube ball socket casing cap—Add note (Cast iron).				
	7800	Steering cross tube ball socket casing cap screw—Add note (Use with cast iron cap).				
		Remove the following:				
30	126037	Steering cross tube ball socket casing cap screw.				
	66209	Steering cross tube ball socket casing cap screw lock wire.				
		Add the following:				
30	137109	Steering cross tube ball socket casing cap (Steel stamping).....			2	2
	5502	Steering cross tube ball socket casing cap screw lock washer.....	4	4	4	4
	7827	Steering cross tube ball socket casing cap screw—Use with steel cap.....			4	4
		Remove the following:				
31	125434	Steering knuckle bearing (inboard) dust washer retainer.				
	125432	Steering knuckle bearing (inboard) spacer.				
		Add the following:				
31	137142	Steering knuckle bearing—inboard—spacer assembly.....	2	2	2	2
34	127727	Front axle brake operating shaft lever right—Change piece number to read 133223.				
	127726	Front axle brake operating shaft lever left—Change piece number to read 133224.				
35	134331	Front axle brake operating shaft support bracket and cap right assembly—Change name to read (Front axle brake operating shaft support bracket and cap left assembly).				

Page No.	Piece No.	Change	No. Required	
			136	143 236 243
35	134330	Front axle brake operating shaft support bracket and cap left assembly—Change name to read (Front axle brake operating shaft support bracket and cap right assembly).		
		Remove the following:		
35	131971	Front axle brake operating shaft trunnion block.		
	131972	Front axle brake operating shaft trunnion block pin.		
	7106	Nut		
	4290	Cotter pin		
	131793	Front axle brake operating shaft trunnion block pin collar.		
		Remove the following:		
39	114143	Gasoline vacuum tank assembly.		
	130808	Gasoline vacuum tank assembly.		
		Add the following:		
39	133212	Gasoline vacuum tank assembly.		
		Add note (Prior to motor No. 212002) to the following:		
41	135917	Hand brake camshaft bushing—inboard.		
	135914	Hand brake camshaft bushing—outboard.		
		Add the following—with note (After motor No. 212001):		
41	136997	Hand brake camshaft bushing—inboard.....	2	2
	136999	Hand brake camshaft bushing—outboard.....	2	2
50	133303	Instrument board cigar lighter—Add note (Cuno type).		
	137651	Instrument board cigar lighter—Cascolite type—Add.....	1	1
		Add the following:		
51	137508	Lubricator—pump plunger knob.....	1	1
53	137666	Lubricator tank filler cap—Add.....	1	1
55	130761	Motor camshaft rocker lever housing—Remove.		
56	131886	Motor camshaft rocker lever housing—Add 2 required for 136-143.		
	125848	Motor camshaft rocker lever housing gasket—Remove.		
	131887	Motor camshaft rocker lever housing gasket—Add 2 required for 136-143.		
	125795	Motor camshaft rocker lever pin—Remove.		
	131888	Motor camshaft rocker lever pin—Add 2 required for 136-143.		
	126464	Motor camshaft sprocket—Remove.		
	132730	Motor camshaft sprocket—Add 1 required for 136-143.		
62	107889	Motor gear housing inspection hole plug—Add note (Prior to motor No. 211472).		
	137134	Motor gear housing inspection hole plug—After motor No. 211471—Add.....	1	1
	7835	Motor support bracket rear bolt—Change piece number to read 7878.		
	129764	Motor crankshaft sprocket assembly—Remove.		
	132733	Motor crankshaft sprocket assembly—Add note (After motor No. 202999) and add 1 required for 136-143.		
63	68601	Motor cylinder core hole plug—Change 4 required to read 5.		
	128641	Motor starting crank—Change piece number to read 137179.		
66	125784	Motor generator sprocket—Remove.		
	132732	Motor generator sprocket—Add note (Prior to motor No. 211472) and add 1 required for 136-143.		
		Add the following—with note (After motor No. 211471):		
66	137145	Motor generator sprocket.....	1	1
71	128641	Motor starting crank—Change piece number to read 137179.		
77	128695	Radiator core and anchorage assembly—Change piece number to read 132787.		
79	124626	Rear axle case cover assembly—Change piece number to read No. 124627 and name to read (Rear axle case cover).		
84	132028	Rear axle brake operating shaft bracket—Remove.		

Page No.	Piece No.	Change	No. Required			
			136	143	236	243
Add the following:						
84	137028	Rear axle brake operating shaft bracket assembly—left.....	1	1
	132049	Rear axle brake operating shaft bracket assembly—right.....	1	1
84	135918	Rear axle brake operating shaft bushing outboard—Add note (Prior to motor No. 212002).				
	132031	Rear axle brake support plate—left—Change piece number to read 137009.				
	132030	Rear axle brake support plate—right—Change piece number to read 137008.				
Add the following with note (After motor No. 212001):						
84	137000	Rear axle brake operating shaft bushing outboard.....	2	2
Add note (Prior to motor No. 211394) to the following:						
88	3987	Speedometer driven pinion and shaft key.				
	124331	Speedometer driven pinion shaft bearing.				
	117981	Speedometer driven pinion shaft bearing.				
	111575	Speedometer driven pinion shaft bearing gasket.				
Add the following—with note (After motor No. 211393):						
88	5321	Speedometer driven pinion and shaft key.....	1	1
	137105	Speedometer driven pinion shaft bearing 4-1/12 to 1.....	1	1
	137104	Speedometer driven pinion shaft bearing 4 $\frac{2}{3}$ to 1.....	1	1
	137108	Speedometer driven pinion shaft bearing gasket.....	1	1
88	136998	Speedometer driving shaft sleeve—Add.....	1	1	1	1
91	114215	Steering pillar tube upper end bearing—Remove note (Prior to unit No. 207010-B).				
Remove the following:						
91	132130	Steering pillar tube upper end bearing.				
	133122	Steering pillar tube upper end bearing washer.				
92	132126	Steering worm bushing lower—Add note (Prior to motor No. 211702).				
Add the following—with note (After motor No. 211701):						
92	137128	Steering worm bushing lower.....	1	1
100	136185	Transmission case vent hole plug—Add.....	2	2
	117983	Transmission driving shaft bearing rear housing cover—Change piece number to read 137107.				
Add the following:						
101	137163	Transmission gear shifter shaft stop cover gasket.....	1	1
	133418	Universal joint shaft assembly.....	1
	133416	Universal joint shaft assembly.....	1	..
Add the following for 136-143:						
104	128381	Wheel hub core—rear.....	2	2
	128383	Wheel hub assembly—rear (Prior to vehicle No. 202001).....	2	2
	129349	Wheel hub assembly—rear (After vehicle No. 202000).....	2	2
	128378	Wheel rim flange ring.....	5	5
106	135107	Wheel carrier assembly—Remove note (After vehicle No. 209801) and add 1 required for 136.				
	135098	Wheel carrier assembly—Remove note (After vehicle No. 209801) and add 1 required for 136-143.				
Remove the following:						
106	125834	Wheel carrier bracket.				
	130737	Wheel carrier bracket.				
Remove the following:						
109	56546	Autophone receiver ground cable.				
	56546	Autophone winder to dash wiring board binding post No. 7 cable.				

Page No.	Piece No.	Change	No. Required 136 143 236 243
		Add note (Push button type) on the following:	
111	33108	Dome light switch—front.	
	132607	Dome light switch.	
	132607	Dome light switch—rear.	
		Add the following—with note (Toggle type):	
111	136662	Dome light switch—front—1 required for models 256-257.	
	136554	Dome light switch—1 required for 253-254.	
	136663	Dome light switch—rear—1 required for 256-257.	
113	126709	Door key lock retaining bushing—Change piece number to read 137638.	
	126708	Door key lock retaining bushing screw—Change piece number to read 137637.	
	132659	Door lock rear right—Change piece number to read 132660.	
	132659	Door lock front left—Change piece number to read 132660.	
	132660	Door lock rear left—Change piece number to read 132659.	
115	132650	Folding seat socket assembly—Change piece number to read 136667.	
120	134092	Moulding—rain gutter—Change name to read (Moulding—rain gutter—right) and quantity from 225 to read 113.	
	133326	Moulding—rain gutter—Change name to read (Moulding—rain gutter—right) and quantity from 239 to read 120.	
	137661	Moulding—rain gutter left—Add 113" for models 253-257.	
	137530	Moulding—rain gutter left—Add 120" for models 254-256.	
		Remove the following:	
122	56546	Rear compartment light to switch cable.	
	56546	Rear compartment light switch to dash wiring board binding post No. 7 cable.	
	102273	Rear compartment light switch to dash wiring board binding post No. 7 cable terminal.	
125	132617	Smoking case cigar lighter—Add note (Cuno type).	
		Add the following:	
125	137659	Smoking case cigar lighter—Cascolite type—Add 1 required for models 253-254-256-257.	
		Remove the following:	
129	134131	Window lock cam—partition.	
	134117	Window lock equalizer—partition.	
	134118	Window lock equalizer plate—partition.	
	134119	Window lock escutcheon plate—partition.	
	134130	Window lock handle—partition.	
	133054	Window lock handle seat screw—partition.	
130	132871	Window glass partition—Add size (21 $\frac{1}{2}$ —21 $\frac{3}{4}$ x 19 $\frac{1}{8}$.)	
		Add the following:	
130	132871	Window glass—partition (23 $\frac{1}{8}$ " x 19 $\frac{1}{8}$ " add 2 required for models 256-257.	
132	138175	Window regulator arm roller—Add x required for models 237-240-241-243-253-254-255-257.	
	123199	Windshield lower sash assembly—Remove for models 253-254-256-257.	
133	136529	Windshield cleaner motor screw—Add 2 required for models 239-242-253-254-256-257.	
134	135990	Windshield visor hinge—Change piece number to read 136664.	
		Add the following:	
139	138061	Door front right trimmed assembly—Add 1 required for model 246.	
		Add the following for model 246—1 required.	
140	138060	Door front left trimmed assembly.	
	138063	Door rear right trimmed assembly.	
	138062	Door rear left trimmed assembly.	

Page No.	Piece No.	Change	No. Required			
			136	143	236	243
141	122152	Door lock—Change piece number to read 119222.				
143	118493	Hand brake lever cutout plate—Add 1 required for 246.				
145	128606	Open top rear curtain assembly—Change piece number to read 128605.				
146	71464	Rumble seat compartment light switch—Add note (Push button type).				
Add the following:						
146	136593	Rumble seat compartment light switch (Toggle type) Add 1 required for 234.				
Remove the following:						
146	56546	Rumble seat compartment light switch to dash wiring board binding post No. 7 cable.				
	102273	Rumble seat compartment light switch to dash wiring board binding post No. 7 cable terminal.				
	56546	Rumble seat compartment light to switch cable.				
Remove the following:						
148	56546	Tonneau light to dash wiring board binding post No. 7 cable.				
	102273	Tonneau light to dash wiring board binding post No. 7 cable terminal.				
	56546	Tonneau light to ground cable.				
151	136529	Windshield cleaner motor screw—Add 2 required for models 234-244-245-246.				

PackardInfo.com