

REPAIR KITS AND SETS SECTION

In this section all Kits and Sets shown elsewhere in the Parts Book are listed in numerical sequence of code numbers. Following the Kit or Set name will be found the part numbers of all Kits or Sets having the same function but used on different models, together with the detail parts which are included in each Kit or Set.

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
REPAIR KITS AND SETS				REPAIR KITS AND SETS—Continued			
1.019		REPAIR KIT - BRAKE MASTER CYLINDER		1.400		SHOE SET - BRAKE SHOE AND LINING (Cont'd)	
		333751 includes:				351210 includes:	
		1 - 303003 piston assembly				2 - 371043 lining and link assembly (primary)	
		1 - 303026 piston cup				2 - 379051 lining and link assembly (secondary)	
		1 - 303025 valve assembly				351651 includes:	
		1 - 351864 valve seat				2 - 371120 lining and link assembly (primary)	
		1 - 303007 boot				2 - 379048 lining and link assembly (secondary)	
		242503 includes:					
		1 - 234863 piston assembly					
		1 - 234865 piston cup					
		1 - 234861 valve assembly					
		1 - 303007 boot					
1.029		REPAIR KIT - BRAKE WHEEL CYLINDER		1.412		LINING SET - BRAKE	
		333754 includes:				338371 includes:	
		2 - 302965 cup				2 - 338679 lining (primary)	
		2 - 302970 boot				2 - 379046 lining (secondary)	
		333753 includes:				68 - 303074 rivets	
		2 - 302964 cup				338410 includes:	
		2 - 302970 boot				2 - 338020 lining (primary)	
		333752 includes:				2 - 379045 lining (secondary)	
		2 - 304888 cup				72 - 303074 rivets	
		2 - 302970 boot				239142 includes:	
		242505 includes:				2 - 234754 lining (primary)	
		2 - 237410 cup				2 - 379044 lining (secondary)	
		2 - 237408 boot				72 - 303074 rivets	
		242504 includes:				338370 includes:	
		2 - 237413 cup				2 - 338680 lining (primary)	
		2 - 302970 boot				2 - 379043 lining (secondary)	
						68 - 303074 rivets	
1.306		RUBBER SET - BRAKE AND CLUTCH PEDAL				351650 includes:	
		98766 includes:				2 - 351669 lining (primary)	
		2 - 169182 pedal rubber				2 - 379037 lining (secondary)	
						68 - 303074 rivets	
1.400		SHOE SET - BRAKE SHOE AND LINING		3.1166		RUBBER SET - CLUTCH AND BRAKE PEDAL	
		351209 includes:				98766 includes:	
		2 - 371209 lining and link (primary)				2 - 169182 pedal rubber	
		2 - 379054 lining and link (secondary)					
		351211 includes:		3.3001		REPAIR KIT - GEARSHIFT IDLER LEVERS AND LINKAGE	
		2 - 378487 lining and link assembly (primary)				382837 includes:	
		2 - 379033 lining and link assembly (secondary)				1 - 360365 lever assembly (direct & 2nd)	
		354063 includes:				1 - 360357 lever assembly (1st & reverse)	
		2 - 371988 lining and link assembly (primary)				2 - 373387 bearing seal	
		2 - 379047 lining and link assembly (secondary)				3 - 232160 bearing seal spacer	
						6 - 333761 friction washer	
						1 - 373454 tie rod	
						1 - 7191 tie rod cotter pin	
						2 - 371546 rod	
						2 - 371521 rod	
						15 - 338406 rod spring washer	

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
REPAIR KITS AND SETS—Continued				REPAIR KITS AND SETS—Continued			
3.3001		REPAIR KIT - GEARSHIFT IDLER LEVERS AND LINKAGE (Cont'd)		4.0305		POINT SET - DISTRIBUTOR BREAKER (Cont'd)	
		382837 includes: (Cont'd)				373326 includes:	
		6 - 360432 rod bushings				1 - D-184038 contact point and support	
		9 - 360444 rod washer				1 - 317972 breaker lever	
		1 - 3874 rod washer				354262 includes:	
		4 - 4290 rod cotter pin				1 - IGP-1047M point	
		1 - 371572 shaft				1 - IGW-3028 arm	
		1 - 3884 shaft washer				354263 includes:	
		1 - 4292 shaft washer cotter pin				1 - IGT-1049LM point	
		382838 includes:				1 - IGP-3028L arm	
		1 - 360364 lever assembly (direct & 2nd)		4.1100		CABLE SET - IGNITION	
		1 - 360358 lever assembly (1st & reverse)				378402 includes:	
		2 - 373387 bearing seal				2 - 317537 spark plug cable assembly #1 & 2	
		1 - 232159 bearing seal spacer				3 - 317534 spark plug cable assembly #2-4-5	
		6 - 333761 friction washer				1 - 317532 spark plug cable assembly #3	
		1 - 371532 shaft				1 - 351045 spark plug cable assembly #7	
		1 - 3884 shaft washer				1 - 351046 spark plug cable assembly #8	
		1 - 7188 shaft nut				1 - 373736 ign. coil to distributor cable assembly	
		1 - 4292 shaft cotter pin				379573 includes:	
		1 - 373454 shaft tie rod				2 - 317537 spark plug cable assembly #1 & 5	
		1 - 7191 shaft tie rod cotter pin				2 - 317534 spark plug cable assembly #2 & 3	
		1 - 360374 rod (idler lever end)				1 - 317535 spark plug cable assembly #4	
		1 - 360372 rod (steering gear end)				1 - 351046 spark plug cable assembly #6	
		1 - 360370 rod (idler lever end)				1 - 378364 ign. coil to distributor cable assembly	
		1 - 371521 rod (steering gear end)				382841 includes:	
		4 - 3874 rod washer				1 - 351046 spark plug cable assembly #1	
		6 - 4290 rod cotter pin				1 - 317537 spark plug cable assembly #2	
		4 - 360444 rod washer				2 - 317534 spark plug cable assembly #3 & 4	
		15 - 338406 rod spring washer				1 - 317535 spark plug cable assembly #5	
		6 - 360432 rod bushing				2 - 351045 spark plug cable assembly #6 & 7	
		382839 includes:				1 - 367984 spark plug cable assembly #8	
		1 - 360364 lever assembly (direct & 2nd)				1 - 373736 coil to distributor cable assembly	
		1 - 360358 lever assembly (1st & reverse)		4.22285		POINT SET - OVERDRIVE SOLENOID	
		2 - 373387 bearing seal				382861 includes:	
		1 - 232159 bearing seal spacer				1 - D-1865935 contact point	
		6 - 333761 friction washer				1 - D-1879397 contact and supporting spring assembly	
		1 - 371532 shaft				5.04005	
		1 - 3884 shaft washer				KIT - CRANKSHAFT AND BEARINGS	
		1 - 7188 shaft nut				387686 includes:	
		1 - 4292 shaft cotter pin				1 - 304854 crankshaft	
		1 - 360386 shaft tie rod				1 - 387656 crankshaft bearing set	
		1 - 7191 shaft tie rod cotter pin				8 - 387600 connecting rod bearing assembly	
		1 - 360377 rod (idler lever end)				4 - 384764 lockplate	
		1 - 371521 rod (steering gear end)				2 - 300014 lockplate	
		1 - 360390 rod (idler lever end)				16 - 7699 lock nut	
		1 - 360372 rod (steering gear end)					
		6 - 360432 rod bushing					
		4 - 360444 rod washer					
		4 - 3874 rod washer					
		6 - 4290 rod cotter pin					
		15 - 338406 rod spring washer					
4.0305		POINT SET - DISTRIBUTOR BREAKER					
		364989 includes:					
		1 - IGS-1149 point					
		1 - IGP-3028 arm					

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
REPAIR KITS AND SETS—Continued				REPAIR KITS AND SETS—Continued			
5.04005		KIT - CRANKSHAFT AND BEARINGS (Cont'd)		5.0401		BEARING SET - CRANKSHAFT (Cont'd)	
	387685	includes:			387660	includes:	
		1 - 315703 crankshaft				1 - 387616 bearing assembly #1	
		1 - 387652 crankshaft bearing set				6 - 387640 bearing assembly #2-3-4-6-7-8	
		6 - 387600 connecting rod bearing assembly				1 - 387644 bearing assembly #9	
		3 - 384764 lockplate				1 - 387648 bearing assembly #5	
		2 - 300014 lockplate			387661	includes:	
		12 - 7699 lock nut				1 - 387617 bearing assembly #1	
	387688	includes:				6 - 387641 bearing assembly #2-3-4-6-7-8	
		1 - 362034 crankshaft				1 - 387645 bearing assembly #9	
		1 - 387660 crankshaft bearing set				1 - 387649 bearing assembly #5	
		8 - 387604 connecting rod bearing assembly			387662	includes:	
		8 - 384764 lockplate				1 - 387618 bearing assembly #1	
		2 - 300014 lockplate				6 - 387642 bearing assembly #2-3-4-6-7-8	
5.0401		BEARING SET - CRANKSHAFT				1 - 387646 bearing assembly #9	
	387656	includes:				1 - 387650 bearing assembly #5	
		1 - 387612 bearing assembly #1			387663	includes:	
		2 - 387624 bearing assembly #2 & 4				1 - 387619 bearing assembly #1	
		1 - 387608 bearing assembly #3				6 - 387643 bearing assembly #2-3-4-6-7-8	
		1 - 387632 bearing assembly #5				1 - 387647 bearing assembly #9	
	387657	includes:		5.0700		GASKET SET - COMBINATION (COMPLETE ENGINE)	
		1 - 387613 bearing assembly #1			338687	includes:	
		2 - 387625 bearing assembly #2 & 4				1 - 324284 head gasket	
		1 - 387609 bearing assembly #3				1 - 300169 gear cover gasket	
		1 - 387633 bearing assembly #5				1 - 300170 gear cover gasket	
	387658	includes:				1 - 300067 outlet flange gasket	
		1 - 387614 bearing assembly #1				1 - 348526 cylinder head outlet gasket	
		2 - 387626 bearing assembly #2				1 - 302311 vent outlet gasket	
		1 - 387610 bearing assembly #3				1 - 300190 distributor gasket	
		1 - 387634 bearing assembly #5				1 - 327807 fuel pump gasket	
	387659	includes:				1 - 354755 oil pan gasket set	
		1 - 387615 bearing assembly #1				1 - 111192 drain plug gasket	
		2 - 387627 bearing assembly #2 & 4				1 - 300735 oil pump gasket	
		1 - 387611 bearing assembly #3				1 - 303930 oil pump cover gasket	
		1 - 387635 bearing assembly #5				1 - 358382 valve cover gasket set	
	387652	includes:				4 - 129439 screw gasket	
		1 - 387608 bearing assembly #1				1 - 320605 water pump gasket	
		2 - 387612 bearing assembly #2 & 3				1 - 320585 water pump cover gasket	
		1 - 387632 bearing assembly #4				1 - 324552 end plate gasket	
	387653	includes:				1 - 351093 manifold gasket set	
		1 - 387609 bearing assembly #1				1 - 300103 gear cover oil retainer assembly	
		2 - 387613 bearing assembly #2 & 3				2 - 300191 crankshaft rear bearing cap oil seal	
		1 - 387633 bearing assembly #4			338817	includes:	
	387654	includes:				1 - 335676 head gasket	
		1 - 387610 bearing assembly #1				1 - 348526 cylinder head outlet gasket	
		2 - 387614 bearing assembly #2 & 3				1 - 300190 distributor gasket	
		1 - 387634 bearing assembly #4				1 - 324552 front end gasket	
	387655	includes:				1 - 327807 fuel pump gasket	
		1 - 387611 bearing assembly #1				1 - 300169 gear cover gasket	
		2 - 387615 bearing assembly #2 & 3				1 - 300170 gear cover gasket	
		1 - 387635 bearing assembly #4				1 - 303906 manifold gasket set	

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
REPAIR KITS AND SETS—Continued				REPAIR KITS AND SETS—Continued			
5.0700		GASKET SET - COMBINATION (COMPLETE ENGINE) (Cont'd)		5.0902		GASKET SET - EXHAUST AND INTAKE MANIFOLD	
	338817	includes: (Cont'd)			351093	includes:	
		1 - 378859 oil pan gasket set				2 - 330774 manifold gasket (front and rear)	
		1 - 111192 drain plug gasket				1 - 330775 manifold gasket (center)	
		1 - 300735 oil pump gasket				1 - 315157 exhaust pipe flange gasket	
		1 - 358381 valve cover gasket set				1 - 362257 carburetor assembly gasket	
		4 - 129439 screw gasket			303906	includes:	
		1 - 303930 oil pump cover gasket				1 - 300414 exhaust pipe flange gasket	
		1 - 320585 water pump cover gasket				2 - 362813 manifold gasket (front and rear)	
		1 - 320605 water pump gasket				1 - 300037 manifold gasket (center)	
		1 - 300103 gear cover oil retainer assembly				2 - 338267 carburetor gasket	
		2 - 300191 crankshaft rear bearing cap oil seal				1 - 300100 exhaust to intake manifold gasket	
	373678	includes:			371230	includes:	
		1 - 371230 manifold gasket set				3 - 354706 exhaust manifold gasket	
		1 - 341364 head gasket				6 - 354707 exhaust & intake manifold gasket	
		1 - 348828 flange gasket				1 - 348465 carburetor assembly gasket (upper)	
		1 - 300190 distributor gasket				1 - 341592 carburetor assembly gasket (lower)	
		1 - 341587 end plate gasket (left)				1 - 141535 exhaust pipe flange gasket	
		1 - 341588 end plate gasket (right)			5.09095	REPAIR KIT - EXHAUST MANIFOLD HEAT CONTROL VALVE	
		1 - 327807 fuel pump gasket				98780	includes:
		1 - 341612 gear cover gasket (long)					1 - 315061 valve
		1 - 341611 gear cover gasket (short)					1 - 315281 shaft and weight assembly
		1 - 354757 oil pan gasket set					1 - 317788 thermostat retaining ring
		1 - 341579 oil pump gasket					1 - 358764 valve pin
		1 - 341555 oil pump cover gasket					2 - 384214 shaft bushing
		1 - 341668 bracket gasket				98782	includes:
		1 - 358383 valve cover gasket set					1 - 213472 valve
		4 - 129439 screw gasket					1 - 213520 valve shaft
		1 - 320605 water pump gasket					2 - 213480 valve shaft bushing
		1 - 320585 water pump cover gasket					1 - 213518 spacer (long)
		1 - 300103 gear cover oil retainer assembly					1 - 213745 weight key
		2 - 300191 crankshaft rear bearing cap oil seal					1 - 3874 shaft washer
							1 - 4280 shaft cotter pin
5.0701		GASKET SET - CARBON AND VALVE		5.10098		CARTRIDGE AND GASKET KIT - OIL FILTER	
	354427	includes:			351405	includes:	
		1 - 324284 cylinder head gasket				1 - 341722 filter cartridge	
		1 - 348526 cylinder head water outlet flange gasket				1 - 341723 gasket	
		1 - 358382 valve cover gasket set			378579	includes:	
		2 - 362257 carburetor assembly gasket				1 - 378578 filter cartridge	
		1 - 394213 fuel pump bowl gasket (AC-1523096)				1 - 378599 gasket	
	354428	includes:			387888	includes:	
		1 - 335676 cylinder head gasket				1 - 387887 filter cartridge	
		1 - 348526 cylinder head water outlet flange gasket				1 - 387889 gasket	
		1 - 358381 valve cover gasket set		5.1101		GASKET SET - OIL PAN	
		2 - 338267 carburetor assembly gasket				378879	includes:
		1 - 394212 fuel pump bowl gasket (AC-1523128)					1 - 300295 gasket (right)
							1 - 377314 gasket (left)

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
REPAIR KITS AND SETS—Continued				REPAIR KITS AND SETS—Continued			
5.1101		GASKET SET - OIL PAN (Cont'd)		5.14005		KIT - PISTON, RING, PIN & BUSHING (Cont'd)	
	354755	includes:			394075	includes: (Cont'd)	
		1 - 315065 gasket (right)				16 - 303398 bushing	
		1 - 315064 gasket (left)				16 - 190021 lock	
	354757	includes:			394070	includes:	
		1 - 341661 gasket (right)				6 - 348575 piston	
		1 - 341662 gasket (left)				1 - 354717 ring set	
5.1206		KIT - OIL PUMP COVER				6 - 324283 pin	
	304046	includes:				12 - 303398 bushing	
		1 - 303926 cover				12 - 190021 lock	
		1 - 303930 cover gasket			394071	includes:	
		1 - 303927 relief valve piston				6 - 348576 piston	
		1 - 354184 relief valve piston spring				1 - 382886 ring set	
		1 - 303928 relief valve piston spring retainer				6 - 324283 pin	
		1 - 21662 relief valve piston spring retainer gasket				12 - 303398 bushing	
	338955	includes:				12 - 190021 lock	
		1 - 302814 cover				394072	includes:
		1 - 300736 cover gasket				6 - 348577 piston	
		1 - 303911 relief valve ball				1 - 382887 ring set	
		1 - 303912 relief valve spring				6 - 324283 pin	
		1 - 302911 relief valve spring retainer				12 - 303398 bushing	
		1 - 21662 relief valve spring retainer gasket				12 - 190021 lock	
	387665	includes:				394076	includes:
		1 - 341551 cover				8 - 348575 piston	
		1 - 341555 cover gasket				1 - 354721 ring set	
		1 - 303927 relief valve piston				8 - 324283 pin	
		1 - 354434 relief valve piston spring				16 - 303398 bushing	
		1 - 303928 relief valve piston spring retainer				16 - 190021 lock	
		1 - 21662 relief valve piston spring retainer gasket				394077	includes:
5.14005		KIT - PISTON, RING, PIN & BUSHING				8 - 348576 piston	
	394073	includes:				1 - 382888 ring set	
		8 - 348585 piston				8 - 324283 pin	
		1 - 354719 ring set				16 - 303398 bushing	
		8 - 302037 pin				16 - 190021 lock	
		16 - 303398 bushing				394078	includes:
		16 - 190021 lock				8 - 348577 piston	
	394074	includes:				1 - 382889 ring set	
		8 - 348586 piston				8 - 324283 pin	
		1 - 382890 ring set				16 - 303398 bushing	
		1 - 302037 pin				16 - 190021 lock	
		16 - 303398 bushing				5.1705	GASKET SET - VALVE COVER
		16 - 190021 lock					
	394075	includes:				358382	includes:
		8 - 348587 piston					2 - 315039 gasket
		1 - 382891 ring set				358381	includes:
		8 - 302037 pin					2 - 300196 gasket
						358383	includes:
							2 - 341369 gasket

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
REPAIR KITS AND SETS—Continued				REPAIR KITS AND SETS—Continued			
5.1902		REPAIR KIT - WATER PUMP		9.11354		LINKAGE KIT - CARBURETOR THROTTLE CONTROL (Cont'd)	
		98732 includes:				384075 includes: (Cont'd)	
		1 - 362027 shaft and bearing				1 - 338752 clevis clip (bell crank end)	
		1 - 335193 impeller				1 - 338753 clevis clip (carburetor end)	
		1 - 317914 fan hub				384077 includes:	
		1 - 320605 pump assembly gasket				1 - 379299 accelerator pedal push rod lever and bracket assembly	
		1 - 320585 cover gasket				1 - 373078 accelerator pedal push rod lever to relay lever rod	
		1 - 384890 seal assembly				1 - 3906 rod washer	
		1 - 384891 seal thrust washer				1 - 4280 rod cotter pin	
		1 - 320625 bearing lock				1 - 338753 rod end clevis clip (right)	
		98777 includes:				1 - 373087 accelerator relay lever to throttle operating shaft lever rod assembly	
		1 - 362027 shaft and bearing				1 - 338752 rod end clevis clip (left)	
		1 - 335193 impeller				1 - 371956 accelerator relay lever shaft and bracket assembly	
		1 - 341547 fan hub				1 - 378638 motor carburetor throttle operating rod	
		1 - 320605 pump assembly gasket				2 - 3906 rod washer	
		1 - 320585 cover gasket				2 - 4280 rod cotter pin	
		1 - 384890 seal assembly				2 - 190192 rod spring washer	
		1 - 384891 seal thrust washer				1 - 373366 motor carburetor throttle operating shaft assembly	
		1 - 320625 bearing lock				384079 includes:	
5.1917		SEAL KIT - WATER PUMP				1 - 379299 accelerator pedal push rod lever and bracket assembly	
		387664 includes:				1 - 373078 accelerator pedal push rod lever to relay lever rod	
		1 - 384890 seal assembly				1 - 3906 rod washer	
		1 - 384891 seal thrust washer				1 - 4280 rod cotter pin	
		1 - 320585 cover gasket				1 - 338753 rod end clevis clip (right)	
		1 - 320605 pump assembly gasket				1 - 377674 accelerator relay lever to throttle operating shaft lever rod assembly	
6.006		REPAIR KIT - EXHAUST MUFFLER PATCH				1 - 338752 clevis clip (left)	
		351999 includes:				1 - 371956 accelerator relay lever shaft and bracket assembly	
		1 - 354107 patch				1 - 378143 carburetor throttle operating rod assembly	
		2 - 354108 patch clamp				1 - 3906 rod washer	
		2 - ----- bolt				1 - 4280 rod cotter pin	
		2 - ----- lockwasher				1 - 190192 rod spring washer	
		2 - ----- nut				1 - 7523 rod yoke end pin	
9.11354		LINKAGE KIT - CARBURETOR THROTTLE CONTROL				1 - 4280 rod yoke end pin cotter pin	
		384075 includes:				1 - 378234 carburetor throttle operating shaft assembly	
		1 - 379299 accelerator pedal push rod lever and bracket				1 - 377689 carburetor throttle operating shaft bracket (left)	
		1 - 373078 accelerator pedal push rod lever to relay lever rod				382767 includes:	
		1 - 3906 rod washer				1 - 367797 carburetor throttle operating lever assembly	
		1 - 4280 rod cotter pin				1 - 367256 carburetor throttle operating lever link	
		1 - 338753 rod end clevis clip (right)					
		1 - 373107 relay lever to throttle bell crank lower rod assembly					
		1 - 338753 rod end clevis clip (right)					
		1 - 338752 rod end clevis clip (left)					
		1 - 371956 relay lever shaft and bracket assembly					
		1 - 373286 carburetor throttle operating bell crank bracket assembly					
		1 - 367314 carburetor throttle operating rod assembly					

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
REPAIR KITS AND SETS—Continued				REPAIR KITS AND SETS—Continued			
9.2001		REPAIR KIT - FUEL PUMP (Cont'd)		14.1170		SHACKLE KIT - SPRING REAR	
		351074 includes:				356860 includes:	
		1 - AC1537097 diaphragm				2 - 347414 spring rear shackle link	
		1 - AC1523128 bowl gasket				2 - 347412 spring rear shackle outer assembly	
		2 - AC1523106 valve and cage				8 - 347126 spring rear bushing	
		2 - AC1521953 valve and cage gasket					
		1 - 327807 mounting gasket					
		1 - AC1522023 lever pin		15.408		PIN KIT - STEERING KNUCKLE	
		1 - AC1521288 washer				378390 includes:	
11.0125		KIT - HOSE AND CLAMP				2 - 367761 knuckle pin	
		378391 includes:				2 - 339774 knuckle pin bearing	
		1 - 371125 hose, inlet				2 - 338117 knuckle pin bearing lower	
		2 - 371115 hose, outlet				2 - 367629 knuckle pin lock pin	
		6 - 230085 hose clamp				2 - 300278 knuckle pin thrust bearing	
		98795 includes:				2 - 302551 knuckle plug (lower)	
		1 - 371125 hose, inlet				2 - 373919 knuckle plug (upper)	
		1 - 371115 hose, outlet (lower)					
		1 - 320686 hose, outlet (upper)					
		6 - 230085 hose clamp					
		98784 includes:					
		1 - 358002 hose, inlet					
		2 - 371115 hose, outlet					
		6 - 230085 hose clamp					
12.0313		OIL SEAL KIT - REAR AXLE SHAFT		15.5131		PIN KIT - STEERING SUPPORT PIVOT	
		379826 includes:				394268 includes:	
		1 - 384215 bearing oil seal (inner)				1 - 367752 pin	
		1 - 324961 bearing oil seal (outer)				1 - 367754 bushing (front)	
		1 - 354409 bearing oil seal retainer gasket				1 - 367757 bushing (rear)	
		1 - 354414 bearing oil guard gasket				1 - 387818 seal (front)	
		1 - 354504 rear axle shaft nut oil seal				1 - 387817 seal (rear)	
		379822 includes:				1 - 216548 oiler	
		2 - 384121 bearing oil seal (inner)				394269 includes:	
		2 - 334929 bearing oil seal (outer)				1 - 373263 pin	
		2 - 354267 bearing oil guard gasket				1 - 373262 bushing	
		2 - 354411 bearing oil seal retainer gasket				2 - 373267 lockwasher	
		379825 includes:				2 - 377544 seal	
		1 - 384121 bearing oil seal (inner)				1 - 373266 nut	
		1 - 334929 bearing oil seal (outer)				1 - 302739 oiler	
		1 - 354267 bearing oil guard gasket					
		1 - 354411 bearing oil seal retainer gasket					
		379823 includes:		18.0152		REPAIR KIT - UNIVERSAL JOINT	
		2 - 384215 bearing oil seal (inner)				382742 includes:	
		2 - 324961 bearing oil seal (outer)				1 - 303405 cross	
		2 - 354409 bearing oil seal retainer gasket				2 - 303749 cross bearing (flanged)	
		2 - 354414 bearing oil guard gasket				2 - 364854 cross bearing (round)	
		2 - 354504 rear axle shaft nut oil seal				4 - 303409 cross bearing dust shield	
						2 - 302877 bolt lock plate	
						4 - 316293 bolt	
						4 - 303407 bearing cork washer	
						2 - 364862 bearing retainer	

REPAIR KITS AND SETS

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
REPAIR KITS AND SETS—Continued							
18.0152	REPAIR KIT - UNIVERSAL JOINT (Cont'd)						
	382741 includes:						
	2 -	364670 ball and roller assembly					
	2 -	364671 trunnion center button and spring					
	2 -	364674 trunnion thrust washer					
	1 -	364672 trunnion body gasket					
	1 -	364669 trunnion pin					
	1 -	364673 dust cover					
	1 -	364676 dust cover clamp (large)					
	1 -	364675 dust cover clamp (small)					
	382852 includes:						
	1 -	327602 cross					
	4 -	327606 cross bearing cork washer					
	4 -	327603 cross bearing dust shield					
	4 -	225557 cross bearing retainer					
	4 -	225555 cross bearing					
	2 -	327517 cross bearing clamp					

PackardInfo.com