

RIGHT HAND DRIVE & SPECIAL VEHICLE SECTION

In this Section are listed those parts which are used only on Right Hand Drive cars or special vehicles such as Taxicabs, Hearses ect.

If the desired function cannot be located in the Group List, it will be found in this Section.

A solid triangle (▲) preceding the code number in the Group List indicates that a part with the same function is used on either a RHD car, or a special vehicle but is not used on a standard LHD car.

A function in the Group List not identified by a solid triangle indicates that the parts listed are used on both RHD and LHD cars of the models shown.

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
BONNET				BRAKE CYLINDER—Continued			
0.0071	CLAMP - LOCK			1.0011	BRACKET - BRAKE MASTER CYLINDER & BRAKE PEDAL SHAFT (Cont'd)		
372294	front, right, 2130		1	8093	Screw 7/16-14 x 1 (50.003) RHD, 2000-01-10-11-2100-01-11		2
383638	rear, right, 2130		1	5508	Lockwasher 7/16 (50.220) RHD, 2000-01-10-11-2100-01-11		2
372295	front, left, 2130		1				
383639	rear, left, 2130		1	1.0100	BOLT - MASTER CYLINDER OUTLET CONNECTION		
0.00721	SPRING - LOCK CLAMP BRACKET TO LOCKING LEVER			316861	RHD, 2000-01-10-11-2100-01-11		1
383599	2130		2	1.016	SPRING & RETAINER ASSEMBLY - MASTER CYLINDER PISTON RETURN		
0.008	HANDLE - LOCK			378788	RHD, 2000-01-10-11-2100-01-11		1
383594	2130		2				
6044	Washer 5/16 internal (50.230) 2130		2	HAND BRAKE			
7258	Nut 5/16-24 (50.100) 2130		2	1.106	BRACKET ASSEMBLY - LEVER		
0.0080	BEARING - LOCK HANDLE SLEEVE			372247	RHD, 2000-01-10-11-2100-01-11		1
383597	2130		2	1.108	CABLE ASSEMBLY - LEVER		
6361	Washer 3/4 (50.200) 2130		2	379467	RHD, 2000-01-10-11-2100-01-11		1
383598	Nut 3/4-16, 2130		2				
0.0081	ESCUTCHEON - LOCK HANDLE			BRAKE PEDAL			
383595	2130		2	1.300	PEDAL - BRAKE		
0.0082	CAP - LOCK HANDLE ESCUTCHEON			378457	RHD, 2000-01-10-11-2100-01-11		1
383596	2130		2	1.302	CONNECTING ROD - PEDAL TO MASTER CYLINDER		
0.00831	LEVER - LOCK HANDLE LOCKING			378460	RHD, 2000-01-10-11-2100-01-11		1
383630	right, 2130		1	1.303	PIN - PEDAL TO MASTER CYLINDER CONNECTING ROD		
383631	left 2130		1	324464	RHD, 2000-01-10-11-2100-01-11		1
0.0084	ROD LINK - LOCK HANDLE TO REAR LOCK CLAMP CONNECTING			1.3065	SHAFT - PEDAL		
383632	right, 2130		1	378438	RHD, 2000-01-10-11-2100-01-11		1
383633	left, 2130		1	216549	Connector, Lubricator (50.700) RHD, 2000-01-10-11-2100-01-11		1
3874	Washer 5/16 (50.220)		4	7766	Screw 1/4-20 x 5/8, tapping, RHD, 2000-01-10-11		1
4291	Cotter pin 3/32 x 3/4 (50.240) 2130		4	8138	Screw 5/16 x 1/2 (50.003) RHD, 2100-01-11		1
0.00841	SPRING - LOCK HANDLE TO REAR LOCK CLAMP CONNECTING ROD ANTI-RATTLE			5502	Lockwasher 1/4 (50.220) RHD		1
373764	2130		4	BRAKE SHOES			
BRAKE				1.405	PIN - SHOE ANCHOR		
BRAKE CYLINDER				338259	rear, 2130		2
1.0005	CYLINDER ASSEMBLY - MASTER			1.407	SPRING - SHOE ANCHOR PIN TO SHOE		
378882	RHD, 2000-01-10-11-2100-01-11		1	315838	front, 2130		4
7244	Screw 3/8-16 x 7/8 (50.003) RHD, 2000-01-10-11-2100-01-11		3	303836	rear, secondary, 2130		2
5506	Lockwasher 3/8 (50.220) RHD, 2000-01-10-11-2100-01-11		3	303837	rear, primary, 2130		2
1.001	CYLINDER - MASTER			1.409	SPRING - SHOE HOLD DOWN		
378756	RHD, 2000-01-10-11-2100-01-11		1	303064	front, 2130		4
1.0011	BRACKET - BRAKE MASTER CYLINDER & BRAKE PEDAL SHAFT			237893	rear, 2130		4
378406	RHD, 2000-01-10-11-2100-01-11		1				

RIGHT HAND DRIVE & SPECIAL VEHICLE SECTION ALPHABETICAL INDEX—CHASSIS

BONNET

Lock Clamp	0.0071
Bracket to Lever Spring.	0.00721
Lock Handle.	0.008
Escutcheon	0.0081
Cap.	0.0082
Locking Lever.	0.00831
Sleeve Bearing	0.0080
to Rear Clamp Connecting Rod Link.	0.0084
Anti-Rattle Spring	0.00841

BRAKE

Hand Brake	
Cable.	1.108
Lever Bracket.	1.106
Master Cylinder Assembly	1.0005
and Brake Pedal Shaft Bracket.	1.0011
Cylinder	1.001
Outlet Connection Bolt	1.0100
Piston Return Spring	1.016
Pedal.	1.300
Connecting Rod	1.302
Pin.	1.303
Shaft.	1.3065
Shoe	
Anchor Pin	1.405
to Shoe Spring	1.407
Hold Down Spring	1.409
Tubing	
Front End Junction	1.606
Front End Junction to Brake Hose	1.601
Master Cylinder to Front Brake Hose.	1.6025
Master Cylinder to Front End Junction.	1.603
Rear Axle Junction to Front End Junction	1.6045

BUMPER

Rear	2.0005
Stone Shield	2.0115
Support Bar.	2.013

CLUTCH

Cover Plate Assembly	3.000
Driven Plate & Hub Assembly.	3.005

CLUTCH CONTROL

Pedal.	3.109
Cover (toe board).	3.1125
Insulator.	3.1126
Pad.	3.114
Retracting Spring.	3.115
Shaft.	3.1041
Bracket.	3.1051
Throwout Bearing & Sleeve.	3.148
Throwout Cable	3.1167
Pulley	3.1168
Guard.	3.1169
Pivot.	3.11691
Support.	3.11692

ELECTRICAL

Headlight	
Dimmer Switch.	4.1328
Horn	
Button Cable Strap	4.10261
Ignition Coil	
and Switch	4.1200
Switch & Cable	4.1205
Overdrive	
Auxiliary Wiring Harness	4.2208
Strap.	4.2209
Reverse Warning Buzzer	4.1525
Gasket	4.1526
Switch	4.1527
Bracket.	4.1528
Cable (to body wiring)	4.1529
Cable (to gas gauge)	4.1530
Clamp.	4.1531
Tail Light	4.1600
Body	4.1602
Cable & Socket	4.1611
Liner.	4.1612
Door	4.1620
Glass.	4.1622
Fuse	4.16232
Block.	4.16231
Gasket (to body)	4.1601
Tell Tale Lamp	4.166
Bulb	4.1665
Wiring Cables & Harness	
Front Harness.	4.2320
Clip	4.2321
Strap.	4.23275
Rear Harness	4.23212

ENGINE

Assembly (stripped).	5.0000
Accelerator - See Carburetor Control	
Cylinder	
Ventilator Outlet Tube	5.0518
Ventilator Valve	5.05216
Reducer.	5.05217
Tube (to cylinder)	5.05213
Connector.	5.05218
Flywheel	5.0600
Housing.	5.0603
Manifold	
Intake	5.0920
Throttle Control Rod	5.0928
Lever.	5.0931
Shaft.	5.0933
Oil Filler Cap	5.1001
Oil Filter	5.1009
Bracket.	5.1010
Support.	5.1013
Cartridge & Gasket Kit	5.10098
Gasket	5.10097
Inlet Tube	5.1015
Oil Level Indicator.	5.1102
Supports	
Channel & Bracket (rear)	5.1607
Brace.	5.16071

RIGHT HAND DRIVE & SPECIAL VEHICLE SECTION ALPHABETICAL INDEX—CHASSIS

EXHAUST	
Pipe	6.100
Clamp.	6.1026
Insulator.	6.1027

FRAME.	8.000
-------------------------	-------

FUEL	
Carburetor Control	
Accelerator Pedal	
Push Rod Lever Bracket	9.11362
Push Rod Lever Pin	9.11363
to Relay Lever Rod	9.11365
Relay Levers & Bracket	9.11372
Shaft Bracket.	9.11373
to Carburetor Throttle Bell Crank Rod.	9.11368
to Carburetor Throttle Lever Rod . . .	9.11369
Carburetor Throttle Operating Rod.	9.135

INSTRUMENT BOARD		10.000
Ash Receiver Retainer Screw.		10.0005
Center Panel		10.012
Crash Pad.		10.0121
Glove Box.		10.021
Door		10.022
Hinge.		10.028
Medallion.		10.038
Trim Moulding.		10.0352
Instrument Cluster Panel		10.058
Trim Moulding.		10.0645
Speedometer.		10.100
Cable & Shaft.		10.127

REAR AXLE	
Carrier Assembly	12.001
Driving Gear & Pinion	12.005

SHOCK ABSORBER	
Front.	13.000
Rear	13.001

SPRINGS	
Front.	14.000
Rear	14.100

STEERING	
Column	15.3002
Brace (to cowl).	15.3072
Bracket (to instrument board).	15.303
Cap.	15.3045
Clamp.	15.301
Grommet.	15.302
Shroud	15.3075
to Dash Insulation	15.3074
Connecting Rod	15.000
Spacer	15.009
Gear	15.310
Case	15.313
Cross Shaft.	15.318
Pitman Arm	15.321
Shaft & Worm	15.329

TRANSMISSION	
Assembly (with O.D.)	3.201
Cover.	3.203
Shifter Fork Shaft	3.252
Hole Plug.	3.2063

TRANSMISSION GEARSHIFT	
Idler Lever.	3.300
Shaft.	3.3031
Support.	3.3046
Tie Rod.	3.3045
Bracket.	3.3261
Bushing.	3.3275
to Transmission Rod.	3.306
Selector Rod	3.317
Shaft.	3.325
Lever (direct & 2nd)	3.329
Stop Pin	3.3292
Bracket.	3.3293
to Idler Lever Rod	3.3301
Lever (1st & reverse).	3.328
to Idler Lever Rod	3.3301
Shifter Lever (direct & 2nd)	3.346
Shifter Lever (1st & reverse).	3.347

TRANSMISSION OVERDRIVE	
Adaptor.	3.271
Gasket	3.273
Lockout Cable.	3.2989
Shift Rail	3.2979
Interlock Fulcrum & Oil Baffle	3.298
Interlock Lever.	3.2980
Spring	3.2981
Interlock Plunger.	3.2982

RIGHT HAND DRIVE & SPECIAL VEHICLE SECTION ALPHABETICAL INDEX—BODY

B	
Body Feed Cable	30.600
Body Wiring Set	30.601

C	
Carpet (front)	31.417
Center Pillar	30.120
Trim	31.414
Courtesy Light Switch	30.6118
Hole Cover Plate	30.6119
Cowl Side Panel	30.125
Trim Panel	31.459

D	
Dash Panel	30.130
Insulation	30.131
Dome Light	30.622
Switch	30.626
Plate	30.629
Door - Front	
Check Arm Bracket	30.3043
Formica Panel	31.4398
Trim Panel	30.3438
Fastener	30.3439
Moulding	30.34395
Window	
Finishing Moulding and Dust Seal	30.356
Glass	30.366
and Frame	30.371
Cushion (to frame) (rubber)	30.3705
(to lifter) (rubber)	30.3845
Frame	30.370
Lifter	30.382
Door - Rear	
Check Arm Bracket	30.441
Finger Guard (trimmed)	30.4452
Trim Panel	30.46796
Fastener	30.46797
Moulding	30.468
Window	
Finishing Moulding and Dust Seal	30.480
Glass	30.489
and Frame	30.492
Cushion (to frame) (rubber)	30.4918
(to lifter) (rubber)	30.5005
Frame	30.4916
Lifter	30.500

E	
Electrical Body Feed Cable	30.600
Electrical Body Wiring Set	30.601

F	
Fenders	
Front	30.770
Rear	
Gasoline Filler Lid	30.791

F (Cont'd)	
Floor Mat (front)	31.430
(rear)	31.431
Joint Moulding	31.4315
Foot Rest	30.014
End Plate	30.0165
Formica Trim Panels	31.4398

I	
Imitation Leather	31.481

L	
License Light	30.634
Body	30.636
Bulb Socket	30.643
Retainer Plate	30.6435
Spring	30.648
Cable	30.649
Gasket	30.6355
Glass	30.650
Gasket	30.651
Retainer Spring	30.6515
License Plate Bracket (rear)	30.847

P	
Package Tray Top	31.4609
Partition	
Card Case	
Driver Compartment Trim Plate	30.85239
Glass	30.8522
Retainer Strip	30.85224
Lid	30.85235
Catch	30.85236
Striker	30.85237
Knob	30.85238
Light	30.6594
Bracket	30.65942
Bulb	30.6595
Crash Pad	
Panel (untrimmed)	30.8525
Trim Cover	30.85257
Grille	30.848
Moulding	30.8482
Mirror	30.8526
to Roof Bow Bracket	30.8479
Trim Moulding	30.8478
Window - Rear	
Finishing Moulding	30.855
Glass	30.858
Cushion	30.8592
Window - Side (complete)	30.8730
Frame Lower Extension Panel	30.8731
Sliding Window	
Glass	30.8737
and Frame	30.87371
Cushion (to frame)	30.87373
Frame	30.87377
Handle	30.87387
Runway	30.87379

RIGHT HAND DRIVE & SPECIAL VEHICLE SECTION ALPHABETICAL INDEX—BODY

P (Cont'd)

Partition (Cont'd)

Stationary Window	
Glass	30.8737
Cushion	30.87372
Frame	30.87374
Rear Hinge	30.87375
Bracket	30.87376
Toggle (front)	
Bumper (to lower partition)	30.8733
Filler	30.87331
Support	30.8734
Clamp	30.8732
Catch	30.87321
Lock Bracket (upper)	30.87350
Bumper	30.87351
Support	30.8736

R

Rear View Mirror	30.022
Rear Window	
Glass	31.353
Hinge	31.3531
Spacer (rubber)	31.3571
Washer (rubber)	31.3572
Weatherstrip	31.358
Operating Motor	31.368
Spring	31.369
Switch	31.3695
Vacuum Tube	31.370
Grommet	31.371
Hose	31.372
Roof	31.140
Roof Light	30.6669
Access Door	31.4589
Bezel	30.66691
Bulb	30.66692
Glass (center)	30.66693
(side)	30.666935
Gasket	30.66694
Mounting Plate	30.66695
Gasket (to roof)	30.66696
Pressure Ring (rubber)	30.666965
Socket and Cable	30.66697
Connector	30.66698
Jumper Cable	30.666982
Switch	30.666984
Knob	30.666986
Trim Moulding	30.666988
Gasket	30.666989

S

Seat - Folding

Back (trimmed)	30.88525
(untrimmed)	30.8852
Trim Cover	30.8853
Bottom Cover	30.88543
Catch	30.8855
Dovetail Stud	30.88551
Spring	30.88552
Handle	30.88553
Release Rod	30.88554
Bearing Plate	30.88555

S (Cont'd)

Seat - Folding (Cont'd)

Cover	30.88556
Spring	30.88557
Center Pillar Hinge	30.88558
Cushion (trimmed)	30.88541
Frame (untrimmed)	30.8854
Hinge Pivot Bolt	30.88544
Push Up Lever	30.88545
Spring	30.88546
Shaft	30.88547
Trim Cover	30.88542
Partition Support	30.8857
Scuff Plate	30.8858
Seat - Front	
Adjusting Handle	30.927
Lever and Bracket	30.92723
Relay Spring	30.9277
Shaft, Bracket, and Relay	30.92729
Adjusting Track	30.930
Back	
Cushion (trimmed)	30.89815
Spring	30.900
Trim Cover	30.8982
Foot Rest Trim Cover	30.8987
Frame (trimmed)	30.8981
Rear Trim Cover	30.8985
Bottom Frame (trimmed)	30.9001
Cushion (trimmed)	30.9005
Pad Support	30.9008
Spring	30.908
Trim Cover	30.9006
Side Sill Rubber Mat	31.4314
Trim Moulding	30.9884
Seat - Rear	
Arm Rest (side)	30.9475
Trim Cover	30.9476
Back Cushion (trimmed)	30.9401
Trim Cover	30.9402
Cushion (trimmed)	30.9412
Spring	30.941
Trim Cover	30.9413
Trim Moulding	30.9478
Sun Visor	30.030

T

Trunk

Compartment Light Cable Clip	30.6672
Lid	31.157
Lock Striker Bracket	31.1875
Lining	31.1503
Rack	31.205
Bar Spacer	31.206
Bolt	31.207
Brace	31.208
Bracket	31.209
Clamping Knob	31.210
Spring	31.211
Pivot Pin	31.212
Strap	31.213
Retaining Plate	31.214

W

Wheelhouse Trim Panel	31.46093
Windshield Division Finishing Inside Moulding	31.394

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
BRAKE TUBING				CLUTCH CONTROL—Continued			
1.601		TUBE ASSEMBLY - BRAKE (FRONT END JUNCTION TO BRAKE HOSE)		3.109		PEDAL	
	379147	left, RHD, 2000-01-10-11-2100-01-11	1	379200		RHD, 2000-01-10-11-2100-01-11	1
1.6025		TUBE ASSEMBLY - MASTER CYLINDER TO FRONT BRAKE HOSE		3.1125		COVER ASSEMBLY - CLUTCH & BRAKE PEDAL	
	379149	right, RHD, 2000-01-10-11-2100-01-11	1	378820		RHD, 2000-01-10-11-2100-01-11	1
1.603		TUBE ASSEMBLY - MASTER CYLINDER TO FRONT END JUNCTION		3.1126		INSULATOR - CLUTCH & BRAKE PEDAL COVER	
	379155	RHD, 2000-01-10-11-2100-01-11	1	378819		RHD, 2000-01-10-11-2100-01-11	1
1.6045		TUBE ASSEMBLY (REAR AXLE JUNCTION TO FRONT END JUNCTION)		3.114		PAD ASSEMBLY - PEDAL	
	379146	RHD, 2000-01-10-11-2100-01-11	1	335928		RHD, 2000-01-10-11-2100-01-11	1
1.606		JUNCTION ASSEMBLY - FRONT END		3.115		SPRING - PEDAL RETRACTING	
	302703	RHD, 2000-01-10-11-2100-01-11	1	379213		RHD, 2000-01-10-11-2100-01-11	1
	303939	Screw 5/16-18 x 1/2 hex. hd., RHD, 2000-01-2100-01-11	1	3.1167		CABLE ASSEMBLY - CLUTCH THROWOUT	
				378515		RHD, 2000-01-10-11-2100-01-11	1
				7515		Yoke end 5/16 adj., pedal end, (50.560)	
						RHD	1
				7258		Nut 5/16-24, yoke, end (50.100) RHD	1
				7525		Pin 5/16, yoke end, (50.555) RHD	1
				4289		Cotter pin 3/32 x 1/2, yoke end pin, (50.240) RHD	1
				302481		Nut 5/16-24 adj., shifter end, (50.150) RHD	1
						RHD	1
				7005		Lock nut 5/16-24, shifter end, (50.100) RHD	1
						RHD	1
				4289		Cotter pin 3/32 x 1/2, (50.240) RHD	1
BUMPER				3.1168		PULLEY - CLUTCH THROWOUT CABLE	
2.0005		BUMPER ASSEMBLY - REAR		373635		RHD, 2000-01-10-11-2100-01-11	1
	387509	with trunk rack, 2130.	1	3.1169		GUARD ASSEMBLY - CLUTCH THROWOUT CABLE PULLEY	
2.0115		SHIELD ASSEMBLY - REAR STONE		373630		RHD, 2000-01-10-11-2100-01-11	1
	383547	used with trunk rack, 2130	1	373696		Bolt 5/16-24 x 1-1/8 hex. hd., RHD, 2000-01-10-11-2100-01-11	1
2.013		BAR - REAR SUPPORT		7105		Nut 5/16-24 (50.110) RHD, 2000-01-10-11-2100-01-11	1
	387508	inner, left, with trunk rack, 2130	1	4280		Cotter pin 1/16 x 1/2 (50.240) RHD, 2000-01-10-11-2100-01-11	1
CLUTCH and TRANSMISSION				3.11691		PIVOT ASSEMBLY - CLUTCH THROWOUT CABLE PULLEY	
CLUTCH ASSEMBLY				373640		RHD, 2000-01-10-11-2100-01-11	1
3.000		PLATE ASSEMBLY - COVER (PRESSURE PLATE)		4291		Cotter pin 3/32 x 3/4 (50.240) RHD, 2000-01-10-11-2100-01-11	1
	371782	2130	1	3.11692		SUPPORT - CLUTCH THROWOUT CABLE PULLEY	
3.005		PLATE AND HUB ASSEMBLY - DRIVEN		378407		RHD, 2000-01-10-11-2100-01-11	1
	356935	2130	1	7244		Screw 3/8-16 x 7/8 hex. hd., (50.003) RHD, 2000-01-10-11-2100-01-11	2
CLUTCH CONTROL				5506		Lockwasher 3/8 (50.003) RHD, 2000-01-10-11-2100-01-11	2
3.1041		SHAFT - PEDAL		3.148		BEARING AND SLEEVE ASSEMBLY - CLUTCH THROWOUT	
	378438	RHD, 2000-01-10-11-2100-01-11	1	341817		RHD, 2000-01-10-11-2100-01-11	1
	8138	Screw 5/16 x 1/2 hex. hd., tapping, RHD, 2000-01-10-11-2100-01-11	1				
3.1051		BRACKET - PEDAL SHAFT					
	378562	RHD, 2000-01-10-11-2100-01-11	1				
	6987	Screw 3/8-16 x 3 (50.003) RHD, 2000-01-10-11-2100-01-11	2				
	7388	Screw 3/8-24 x 1 (50.003) RHD, 2000-01-10-11-2100-01-11	1				
	5506	Lockwasher 3/8 (50.220) RHD, 2000-01-10-11-2100-01-11	3				
	378548	Spacer, bolt, RHD, 2000-01-10-11-2100-01-11	1				

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
TRANSMISSION			
3.201		TRANSMISSION AND OVERDRIVE ASSEMBLY	
901010		RHD, 2000-01-10-11-2100-01-11	1
901149		RHD, 2000-01-10-11-2100-01-11	1
3.203		COVER ASSEMBLY -	
387667		RHD, 2000-01-10-11-2100-01-11	1
3.2063		PLUG - COVER SHIFTER FORK SHAFT HOLE (Not used with Electromatic Clutch)	
335663		RHD, 2000-01-10-11-2100-01-11	2
3.252		SHAFT - SHIFTER FORKS	
360442		RHD, 2000-01-10-11-2100-01-11	2
TRANSMISSION-OVERDRIVE			
3.271		ADAPTER - OVERDRIVE	
347551		RHD, 2000-01-10-11-2100-01-11	1
3.273		GASKET - OVERDRIVE CASE TO ADAPTER	
355020		RHD, 2000-01-10-11-2100-01-11	1
3.2979		RAIL - SHIFT	
355048		RHD, 2000-01-10-11-2100-01-11	1
3.298		BAFFLE ASSEMBLY - SHIFT RAIL INTERLOCK FULCRUM AND OIL	
347838		RHD, 2000-01-10-11-2100-01-11	1
3.2980		LEVER - SHIFT RAIL INTERLOCK	
347840		RHD, 2000-01-10-11-2100-01-11	1
3.2981		SPRING - SHIFT RAIL INTERLOCK LEVER	
347877		RHD, 2000-01-10-11-2100-01-11	1
3.2982		PLUNGER - SHIFT RAIL INTERLOCK	
347841		long, RHD, 2000-01-10-11-2100-01-11	1
347733		Plug, drill hole, RHD, 2000-01-10-11	2
3.2989		CABLE ASSEMBLY - LOCKOUT	
379448		Clip, to flywheel housing, RHD, 2000-01-10-11-2100-01-11	1
125641		Clip, to steering column clamp, RHD, 2000-01-10-11-2100-01-11	1
TRANSMISSION GEARSHIFT			
3.300		LEVER ASSEMBLY - IDLER	
378494		direct & 2nd., RHD, 2000-01-10-11-2100-01-11	1
378717		first & reverse, RHD, 2000-01-10-11-2100-01-11	1
3.3031		SHAFT - IDLER LEVER	
3914		Washer 1/2 (50.200) RHD, 2000-01-10-11	1
3.3045		TIE ROD - IDLER LEVER SHAFT	
360386		RHD, 2000-01-10-11-2100-01-11	1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
TRANSMISSION GEAR SHIFT-Continued			
3.3045		TIE ROD - IDLER LEVER SHAFT (Cont'd)	
338406		Spring washer 5/16 (50.242) RHD, 2000-01-10-11-2100-11	2
360444		Washer 5/16, RHD, 2000-01-10-11-2100-01-11	2
3.3046		SUPPORT ASSEMBLY - IDLER LEVER SHAFT	
378428		RHD, 2000-01-10-11-2100-01-11	1
3.306		ROD - IDLER LEVER TO TRANSMISSION	
378566		direct & 2nd., RHD, 2000-01-10-11-2100-01-11	1
378568		first & reverse, RHD, 2000-01-10-11-2100-01-11	1
338405		Washer 5/16, idler lever end, (50.200) RHD, 2000-01-10-11-2100-01-11	2
330344		Spring washer 5/16 (50.242) idler lever end, RHD, 2000-01-10-11	2
		trans. end, RHD, 2000-01-10-11-2100-01-11	2
3.317		ROD ASSEMBLY - SELECTOR	
378727		RHD, 2000-01-10-11-2100-01-11	1
3.325		SHAFT AND HOUSING ASSEMBLY (PRIME)	
384714		RHD, 2000-01-10-11-2100-01-11	1
3.3261		BRACKET - IDLER LEVER SHAFT TIE ROD	
378447		RHD, 2000-01-10-11-2100-01-11	1
378445		Clamp, RHD, 2000-01-10-11-2100-01-11	1
5502		Lockwasher 1/4, clamp, (50.220)	2
7004		Nut 1/4-28, clamp, (50.100)	2
3.3275		BUSHING - IDLER LEVER SHAFT TIE ROD BRACKET	
360432		RHD, 2000-01-10-11-2100-01-11	1
3.328		LEVER - SHAFT (1ST. AND REVERSE)	
360425		RHD, 2000-01-10-11-2100-01-11	1
3.329		LEVER - SHAFT (DIRECT AND 2ND.)	
395296		RHD, 2000-01-10-11-2100-01-11	1
3.3292		PIN - GEARSHIFT SHAFT (DIRECT AND 2ND.) LEVER STOP	
379468		RHD, 2000-01-10-11-2100-01-11	1
7169		Lock nut 1/4-28, self-locking, (50.120) 2000-01-10-11-2100-01-11	2
3.3293		BRACKET - SHAFT (DIRECT AND 2ND.) LEVER STOP PIN	
364471		RHD, 2000-01-10-11-2100-01-11	1
7588		Screw #10-32 x 3/8, to steering column, (50.000)	2
5500		Lockwasher #10 (50.220)	2
6757		Washer #10 (50.200)	2

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
TRANSMISSION GEAR SHIFT—Continued				IGNITION COIL—Continued			
3.330		ROD - SHAFT LEVER 1ST AND REVERSE TO IDLER LEVER		4.1205		SWITCH AND CABLE ASSEMBLY	
378813		idler lever end, RHD, 2000-01-10-11-2100-01-11	1	378805		RHD, 2000-01-10-11-2100-01-10-11 (Auto-Lite)	1
378814		steering gear end, RHD, 2000-01-10-11-2100-01-11	1	378804		RHD, 2000-10-2100 (Delco)	1
330344		Spring washer 5/16, steering gear end, (50.242) RHD, 2000-01-10-11-2100-01-11	1	HEADLIGHT			
360444		Washer 5/16 idler lever end, (50.200)RHD, 2000-01-10-11-2100-01-11	2	4.1328		SWITCH ASSEMBLY - FOOT DIMMER	
338405		Washer 5/16, steering gear end, (50.200) RHD, 2000-01-10-11-2100-01-11	1	303245		RHD, 2000-01-10-11	1
3.3301 ROD - SHAFT LEVER DIRECT AND 2ND. TO IDLER LEVER				REVERSE WARNING BUZZER			
378813		idler lever end, RHD, 2000-01-10-11-2100-01-11	1	4.1525		BUZZER ASSEMBLY - WARNING	
378815		steering gear end, RHD, 2000-01-10-11-2100-01-11	1	383914		2130	1
330344		Spring washer 5/16, steering gear end, (50.242) RHD, 2000-01-10-11-2100-01-11	1	393506		Screw #10-32 x 5/8 oval head, to stone shield, 2130	2
360444		Washer 5/16, idler lever end, (50.200) RHD, 2000-01-10-11-2100-01-11	2	164239		Cup washer, 2130	2
338405		Washer 5/16, steering gear end, (50.200) RHD, 2000-01-10-11-2100-01-11	1	5935		Lockwasher #10 internal (50.230) 2130	2
338405		Washer 5/16, steering gear end, (50.200) RHD, 2000-01-10-11-2100-01-11	1	7002		Nut #8-32 (50.100) 2130	2
3.3301 ROD - SHAFT LEVER DIRECT AND 2ND. TO IDLER LEVER				4.1526		GASKET -	
378813		idler lever end, RHD, 2000-01-10-11-2100-01-11	1	393505		2130	1
378815		steering gear end, RHD, 2000-01-10-11-2100-01-11	1	4.1527		SWITCH	
330344		Spring washer 5/16, steering gear end, (50.242) RHD, 2000-01-10-11-2100-01-11	1	351362		2130	1
360444		Washer 5/16, idler lever end, (50.200) RHD, 2000-01-10-11-2100-01-11	2	351518		Nut 7/16-20, 2130	2
338405		Washer 5/16, steering gear end, (50.200) RHD, 200-01-10-11-2100-01-11	1	4.1528		BRACKET - SWITCH	
3.346 LEVER - DIRECT DRIVE AND 2ND. SPEED SHIFTER				351087		2130	1
335645		RHD, 2000-01-10-11-2100-01-11	1	4.1529		CABLE ASSEMBLY - SWITCH TO BODY WIRING	
3.347 LEVER - FIRST SPEED AND REVERSE SHIFTER				383921		2130	1
335657		RHD, 2000-01-10-11-2100-01-11	1	383492		Connector, 2130	2
ELECTRICAL				4.1530		CABLE ASSEMBLY - SWITCH TO GAS GAUGE	
HORN				383923		2130	1
4.10261		STRAP - BUTTON CABLE		4.1531		CLAMP - SWITCH CABLES STRAP	
146955		to brake tube, RHD, 2000-01-10-11-2100-01-11	2	146995		2130	2
IGNITION COIL				TAIL LIGHT			
4.1200		COIL & SWITCH ASSEMBLY		4.1600		TAIL & STOP LIGHT ASSEMBLY	
378754		RHD, 2000-10-2100 (Delco #1116355)	1	383414		right, RHD, 2111	1
378755		RHD, 2000-01-10-11-2100-01-11 (Auto-Lite)	1	383415		left RHD, 2111	1
4.1601 GASKET - TAIL LIGHT TO BODY				383416		right, RHD, 2111	1
4.1602 BODY				383417		left, RHD, 2111	1
4.1611 CABLE & SOCKET ASSEMBLY				383428		right, RHD, 2111	1
4.1611 CABLE & SOCKET ASSEMBLY				383429		left, RHD, 2111	1
4.1611 CABLE & SOCKET ASSEMBLY				371916		right, RHD, 2111	1
4.1611 CABLE & SOCKET ASSEMBLY				371741		left, RHD, 2111	1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
TAIL LIGHT-Continued			
4.1612	LINER - CABLE & SOCKET ASSEMBLY		
371841	RHD, 2111		2
4.1620	DOOR		
383426	right, RHD, 2111		1
383427	left, RHD, 2111		1
4.1622	GLASS - TAIL LIGHT DOOR		
383420	right, RHD, 2111		1
383421	left, RHD, 2111		1
4.16231	BLOCK - TAIL LIGHT FUSE		
383778	2130-1684		1
8404	Screw #6-32 (50.002)		1
7328	Washer #6 (50.200)		1
3516	Lockwasher #6 (50.220)		1
6474	Nut #6-32 (50.100)		1
4.16232	FUSE - TAIL LIGHT FUSE BLOCK		
302121	2130-1684		1
LAMP-TELL TALE			
4.166	TELL TALE LAMP & CABLE ASSEMBLY - INSTRUMENT BOARD		
383629	2130		1
383492	Connector, to door switch cable, 2130		1
71397	Terminal (50.925) 2130		1
36111	Insulator (50.935) 2130		1
4.1665	BULB - TELL TALE LAMP		
56973	Bulb, 6 C.P., 2130		1
OVERDRIVE			
4.2208	HARNESS ASSEMBLY - AUXILIARY WIRING		
379305	RHD, 2000-01-10-11-2100-01-11		1
379364	to transmission, RHD, 2000-01-10-11-2100-01-11		1
362105	Grommet, to dash, RHD, 2000-01-10-11-2100-01-11		1
4.2209	STRAP - AUXILIARY WIRING HARNESS ASSEMBLY TO FRONT HARNESS		
203905	RHD, 2000-01-10-11-2100-01-11		6
WIRING CABLES & HARNESS-LOW TENSION			
4.2320	HARNESS ASSEMBLY - WIRING FRONT		
379304	RHD, 2000-01-10-11		1
383491	RHD, 2100-01-11		1
4.2321	CLIP - WIRING HARNESS ASSEMBLY FRONT		
371212	to accelerator bracket, RHD, 2000-01-10-11-2100-01-11		2
	to dash, ignition coil lower screw, RHD, 2000-01-10-11-2100-01-11		1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
WIRING CABLES & HARNESS-LOW TENSION-Cont'd.			
4.2321	CLIP - WIRING HARNESS ASSEMBLY FRONT (Cont'd)		
	to dash, RHD, 2000-01-10-11-2100-01-11		2
371211	to dash, RHD, 2000-01-10-11-2100-01-11		2
8099	Screw #12 x 1/2, self-locking, to dash clip, RHD, 2000-01-10-11-2100-01-11		2
6612	Screw 1/4-20 x 1/2, to dash clip, (50.003) RHD, 2000-01-10-11-2100-01-11		2
5502	Lockwasher 1/4 (50.220) RHD, 2000-01-10-11-2100-01-11		2
4.23212	WIRING HARNESS - REAR		
388724	2130		1
4.23275	STRAP - FRONT WIRING HARNESS		
203905	direction signal wires hold-down, RHD, 2111		4
ENGINE			
ENGINE ASSEMBLY			
5.0000	ENGINE ASSEMBLY - STRIPPED (Complete engine less electrical equipment, manifold, clutch and fan.)		
394173	RHD, 2000-10-2100		1
394174	RHD, 2001-11-2101-11		1
CYLINDER			
5.0518	TUBE ASSEMBLY - VENTILATOR OUTLET		
354024	RHD, 2000-01-10-11-2100-01-11		1
5.05213	TUBE AND FLANGE ASSEMBLY - CYLINDER TO VENTILATOR VALVE		
387789	2130		1
5.05216	VALVE ASSEMBLY - CYLINDER VENTILATOR		
387785	2130		1
5.05217	REDUCER - CYLINDER VENTILATOR VALVE ASSEMBLY TO INTAKE MANIFOLD		
387787	2130		1
5.05218	CONNECTOR - CYLINDER VENTILATOR VALVE TO TUBE		
387794	2130		1
FLYWHEEL			
5.0600	FLYWHEEL ASSEMBLY		
356917	2130		1
5.0603	HOUSING ASSEMBLY		
378823	RHD, 2000-01-10-11-2100-01-11		1
378822	Plug, RHD, 2000-01-10-11-2100-01-11		1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
MANIFOLD				SUPPORTS—Continued			
5.0920	MANIFOLD ASSEMBLY - INTAKE			5.16071	BRACE - REAR BRACKET (Cont'd)		
389185	2130		1	378715	left, RHD, 2000-01-10-11-2100-01-11		1
5.0928	ROD - INTAKE MANIFOLD CARBURETOR THROTTLE CONTROL			7387	Screw 3/8-24 x 7/8 (50.003) RHD, 2000-01-10-11-2100-01-11		2
377825	RHD, 2000-10-2100		1	3877	Washer 3/8 (50.200) RHD, 2000-01-10-11-2100-01-11		2
338753	Clip, carburetor end, 2000-10-2100		1	7006	Nut 3/8-24 (50.100) RHD, 2000-01-10-11-2100-01-11		5
338752	Clip, lever end, 2000-10-2100		1	EXHAUST			
5.0931	LEVER - INTAKE MANIFOLD CARBURETOR THROTTLE			PIPE			
341137	RHD, 2000-10-2100		1	6.100	PIPE ASSEMBLY - EXHAUST		
5.0933	SHAFT - INTAKE MANIFOLD CARBURETOR THROTTLE LEVER			378785	RHD, 2000-10-2100		1
315077	RHD, 2000-10-2100		1	378539	RHD, 2001-11-2101-11		1
3907	Washer 1/4 (50.200) 2000-10-2100		1	6.1026	CLAMP		
4280	Cotter pin 1/16 x 1/2 (50.240) 2000-10-2100		1	333477	RHD, 2000-10-2100		1
OIL FILLER and FILTER				333476	RHD, 2001-11-2101-11		1
5.1001	CAP - OIL FILLER			379201	"U" Bolt (50.091) 2000-10-2100		1
232692	2130		1	379202	"U" Bolt (50.091) 2001-11-2101-11		1
5.1009	FILTER & BRACKETS ASSEMBLY - OIL			6359	Washer 5/16 (50.200) 2000-01-10-11-2100-01-11		2
PA387898	2130		1	5504	Lockwasher 5/16 (50.220) 2000-01-10-11-2100-01-11		2
5.10097	GASKET - OIL FILTER			7305	Nut 5/16-18 (50.100) 2000-01-10-11-2100-01-11		2
PA387889	2130		1	6.1027	INSULATOR - CLAMP		
5.10098	CARTRIDGE AND GASKET KIT - OIL FILTER			379210	RHD, 2000-10-2100		2
PA387888	2130		1	379268	RHD, 2001-11-2101-11		2
5.1010	BRACKET - OIL FILTER			FRAME			
PA387886	2130		2	8.000	FRAME ASSEMBLY		
7344	Screw 5/16-18 x 3/4 (50.003) 2130		4	378845	RHD, 2000-01-10-11-2100-01-11		1
3874	Washer 5/16 (50.200) 2130		4	FUEL			
5504	Lockwasher 5/16 (50.220) 2130		4	CARBURETOR CONTROL			
7305	Nut 5/16 (50.100) 2130		2	9.11362	BRACKET - ACCELERATOR PEDAL PUSH ROD LEVER		
5.1013	SUPPORT - OIL FILTER BRACKET			373014	RHD, 2000-01-10-11-2100-01-11		1
387891	2130		1	9.11363	PIN - ACCELERATOR PEDAL PUSH ROD LEVER		
5.1015	TUBE ASSEMBLY - OIL FILTER INLET			373109	RHD, 2000-01-10-11-2100-01-11		1
PA387874	2130		1	9.11365	ROD - ACCELERATOR PEDAL LEVER TO RELAY LEVER		
OIL PAN				378751	RHD, 2000-10-2100		1
5.1102	INDICATOR ASSEMBLY - OIL LEVEL			378750	RHD, 2001-11-2101-11		1
387872	2130		1	3906	Washer 3/16 (50.200) 2000-10-2100		2
SUPPORTS				4280	Cotter pin 1/16 x 1/2 (50.240) 2000-10-2100		2
5.1607	CHANNEL AND BRACKET ASSEMBLY - REAR			9.11368	ROD - ACCELERATOR RELAY LEVER TO CARBURETOR THROTTLE BELL CRANK		
378847	RHD, 2000-01-10-11-2100-01-11		1	378744	long, RHD, 2000-10-2100		1
5.16071	BRACE - REAR BRACKET			367310	short, RHD, 2000-10-2100		1
378881	right, RHD, 2000-01-10-11-2100-01-11		1	379064	long, used with overdrive, RHD, 2000-10-2100		1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
CARBURETOR CONTROL—Continued			
9.11368	ROD - ACCELERATOR RELAY LEVER TO CARBURETOR THROTTLE BELL CRANK (Cont'd)		
373085	short, used with overdrive, RHD, 2000-10-2100		1
3906	Washer 3/16 (50.200) RHD, 2000-10-2100		1
4280	Cotter pin 1/16 x 1/2 (50.240) RHD, 2000-10-2100		1
9.11369	ROD - ACCELERATOR RELAY LEVER TO CARBURETOR THROTTLE LEVER		
378746	long, RHD, 2001-11-2101-11		1
367310	short, RHD, 2001-11-2101-11		1
379024	long, used with overdrive, RHD, 2001-11-2101-11		1
373085	short, used with overdrive, RHD, 2001-11-2101-11		1
3906	Washer 3/16 (50.200) 2001-11-2101-11		2
190192	Spring washer, 2001-11-2101-11		1
4280	Cotter pin 1/16 x 1/2 (50.240) 2001-11-2101-11		2
367303	Nut #10-32, LH thd., 2001-11-2101-11		1
7003	Nut #10-32 (50.100) 2001-11-2101-11		1
367312	Turnbuckle, RHD, 2001-11-2101-11		1
9.11372	SHAFT AND BRACKET ASSEMBLY - ACCELERATOR RELAY LEVERS		
378749	RHD, 2000-10-2100		1
378748	RHD, 2001-11-2101-11		1
378743	Spacer, RHD, 2001-11-2101-11		1
6612	Screw 1/4-20 x 1/2 (50.000) RHD, 2000-10-2100		4
8096	Screw 1/4-20 x 3/4 (50.000) RHD, 2001-11-2101-11		2
9.11373	BRACKET ASSEMBLY - ACCELERATOR RELAY LEVER SHAFT		
335726	RHD, 2000-10-2100		2
9.135	ROD - CARBURETOR THROTTLE OPERATING		
378746	long, RHD, 2001-11-2101-11		1
367310	short, RHD, 2001-11-2101-11		1
INSTRUMENT BOARD			
10.000	INSTRUMENT BOARD ASSEMBLY (LESS GAUGES - MOULDINGS - COMP'T DOOR, ETC.)		
383585	2130		1
375337	RHD, 2000-01-10-11		1
385402	RHD, 2100-01-11		1
10.0005	RETAINER & RIM ASSEMBLY - ASH RECEIVER		
8410	Screw #10 x 3/4 (50.300) 2130-1684		4
10.012	PANEL - CENTER		
392340	2130 (used with crash pad)		1
10.0121	PAD ASSEMBLY - CRASH		
252810	2130-1684		1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
INSTRUMENT BOARD—Continued			
10.0121	PAD ASSEMBLY - CRASH (Cont'd)		
7586	Screw #6 x 3/4 (50.300)		14
8263	Ferrule #6, screw		14
10.021	BOX ASSEMBLY - GLOVE		
375333	RHD, 2000-01-10-11-2100-01-11		1
10.022	PANEL ASSEMBLY - GLOVE BOX DOOR		
375306	RHD, 2000-01-10-11		1
383063	RHD, also order 1 pc. of 385634 spacer for 1612 & 1692 bodies having a push button type lock, 2100-01-11		1
10.028	HINGE ASSEMBLY - GLOVE BOX DOOR		
380421	RHD, 2000-01-10-11-2100-01-11		1
10.0352	MOULDING - GLOVE BOX DOOR TRIM		
375228	RHD, 2000-01-10-11		1
	RHD, with push button lock, 2101-1692, 2111-1612		1
385760	chrome, RHD, 2111		1
385976	paint, RHD, 2100-01		1
10.038	MEDALLION ASSEMBLY - GLOVE BOX DOOR		
382366	2130-1686		1
10.058	PANEL ASSEMBLY - INSTRUMENT CLUSTER (LESS INSTRUMENTS)		
377648	RHD, 2000-01-10-11		1
383061	RHD, 2100-01-11		1
10.0645	MOULDING - INSTRUMENT CLUSTER PANEL TRIM		
377390	chrome, RHD, 2000-01-10-11-2111		1
385983	paint, RHD, 2100-2101		1
SPEEDOMETER			
10.100	SPEEDOMETER		
378680	MPH, brown, RHD, 2000-01		1
379104	MPH, blue, RHD, 2010-11		1
378681	KPH, brown, RHD, 2000-01		1
379105	KPH, blue, RHD, 2010-11		1
382355	MPH, RHD, 2100-01		1
382361	MPH, RHD, 2111		1
382356	KPH, RHD, 2100-01		1
382362	KPH, RHD, 2111		1
10.127	SHAFT ASSEMBLY - CABLE AND		
378332	RHD, 2000-01-10-11-2100-01-11		1
378331	used with overdrive, RHD, 2000-01-10-11-2100-01-11		1
371211	Clip, to dash, (50.600) RHD, 2000-01-10-11-2100-01-11		2
371212	Clip, to dash, used with overdrive, (50.600) RHD, 2000-01-10-11-2100-01-11		2
7653	Screw #10 x 3/8, tapping, (50.300) RHD,		

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
SPEEDOMETER—Continued				COLUMN—Continued			
10.127		SHAFT ASSEMBLY - CABLE AND (Cont'd)		15.301		CLAMP ASSEMBLY - STEERING COLUMN (Cont'd)	
		2000-01-10-11-2100-01-11	2	7005		Nut 5/16-24 (50.100) 2000-01-10-11-2100-01-11	1
6757		Washer #10, to dash, used with overdrive, (50.200) RHD, 2000-01-10-11-2100-01-11	2	15.302		GROMMET - STEERING COLUMN	
				378848		RHD, 2000-01-10-11-2100-01-11	1
REAR AXLE				15.303		BRACKET - COLUMN TO INSTRUMENT BOARD	
CARRIER				378464		RHD, 2000-01-10-11-2100-01-11	1
12.001		CARRIER ASSEMBLY - DIFFERENTIAL Standard Without Overdrive		15.3045		CAP - COLUMN TO INSTRUMENT BOARD BRACKET	
901264		4.54 to 1, 2130	1	378517		RHD, 2000-01-10-11-2100-01-11	1
12.005		GEAR AND PINION ASSEMBLY - DIFFERENTIAL DRIVING Standard Without Overdrive		15.3072		BRACE - INSTRUMENT BOARD TO COWL	
900066		4.54 to 1, 2130	1	375363		RHD 2000-01-10-11-2100-01-11	1
SHOCK ABSORBER				15.3074		INSULATION - COLUMN TO DASH	
13.000		SHOCK ABSORBER - FRONT		378856		RHD, 2000-01-10-11-2100-01-11	1
387536		right, 2130	1	15.3075		SHROUD	
387535		left, 2130	1	384795		RHD 2000-01-10-11-2100-01-11	1
13.001		SHOCK ABSORBER - REAR		GEAR			
387537		2130	2	15.310		STEERING GEAR ASSEMBLY	
SPRINGS				901140		RHD, 2000-01-10-11	1
14.000		SPRING - FRONT		384772		RHD, 2100-01-11	1
387806		Load 1870# rate 90#, 2130	2	15.313		CASE ASSEMBLY	
14.100		SPRING - REAR		378555		RHD, 2000-01-10-11	1
387805		Load 1000# rate 140#, 2130	2	387527		RHD, 2100-01-11	1
STEERING				15.318		SHAFT ASSEMBLY - CROSS	
CONNECTING ROD				351804		RHD, 2000-01-10-11	1
15.000		ROD ASSEMBLY - STEERING CONNECTING		387524		RHD, 2100-01-11	1
378764		RHD, 2000-01-10-11-2100-01-11	1	15.321		PITMAN ARM - STEERING	
15.009		SPACER		378712		RHD, 2000-01-10-11	1
373706		right, RHD, 2000-01-10-11-2100-01-11	1	15.329		SHAFT AND WORM ASSEMBLY	
373705		left, RHD, 2000-01-10-11-2100-01-11	1	378731		RHD, 2000-01-10-11	1
				387528		RHD, 2100-01-11	1
COLUMN							
15.3002		STEERING COLUMN ASSEMBLY					
384777		RHD, 2000-01-10-11-2100-01-11	1				
15.301		CLAMP ASSEMBLY - STEERING COLUMN					
303680		RHD, 2000-01-10-11-2100-01-11	1				
5753		Screw 5/16-24 x 1-7/8 (50.003) 2000-01-10-11-2100-01-11	1				
5504		Lockwasher 5/16 (50.220) 2000-01-10-11-2100-01-11	1				

PackardInfo.com

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
BODY EQUIPMENT				CENTER PILLAR—Continued			
FOOT REST							
30.014		FOOT REST ASSEMBLY (Specify Trim Set No.)		30.120		CENTER PILLAR ASSEMBLY (Cont'd)	
392356		21st, 1684	1	388689		left, 21st, 1684	1
		21st, 2184	1			left, 21st, 2184	1
7320		Washer 3/8 (50.200)		COWL SIDE PANEL			
		21st, 1684	4	30.125		PANEL ASSEMBLY - COWL SIDE	
		21st, 2184	4	392042		right, 21st, 1684	1
349471		Shim, square				right, 21st, 2184	1
		21st, 1684	2	392043		left, 21st, 1684	1
		21st, 2184	2			left, 21st, 2184	1
7306		Nut 3/8-16 (50.100)		380330		right, RHD, 20th, 1502-05-12-15-82-85-88-92-95-98	1
		21st, 1684	2			left, RHD, 20th, 1502-05-12-15-82-85-88-92-95-98	1
		21st, 2184	2	380331		left, RHD, 20th, 1502-05-12-15-82-85-88-92-95-98	1
314915		Nut and washer 3/8-16					
		21st, 1684	2	DASH PANEL			
		21st, 2184	2	30.130		DASH PANEL ASSEMBLY	
30.0165		PLATE - FOOT REST END		388411		21st, 1684-86	1
392351		inner, 21st, 1684	1			21st, 2184-86	1
		inner, 21st, 2184	1	380138		RHD, 20th, 1502-05-12-15-82-85-88-92-95-98	1
392350		outer, 21st, 1684	1			RHD, 21st, 1612-15-82-85-92-95	1
		outer, 21st, 2184	1			RHD, 21st, 2112-15-82-85-92-95	1
6913		Screw #8 x 3/4 (50.340)		30.131		INSULATION - DASH PANEL PAD	
		inner plate, 21st, 1684	4	375303		RHD, 20th, 1502-05-12-15-82-85-88-92-95-98	1
		outer plate, 21st, 1684	2			RHD, 21st, 1612-15-82-85-92-95	1
		inner plate, 21st, 2184	4			RHD, 21st, 2112-15-82-85-92-95	1
		outer plate, 21st, 2184	2	ROOF			
REAR VIEW MIRROR				30.140		ROOF ASSEMBLY	
30.022		MIRROR ASSEMBLY - REAR VIEW		392213		used with roof light equipment, 21st, 1684	1
374239		21st, 1684	1			used with roof light equipment, 21st, 2184	1
		21st, 2184	1	392474		used with roof light equipment, 21st, 1686	1
6914		Screw #10 x 1 (50.300)				used with roof light equipment, 21st, 2180	1
		21st, 1684	2	392683		not used with roof light equipment, 21st, 1684-86	1
		21st, 2184	2			not used with roof light equipment, 21st, 2184-86	1
SUN VISOR				380452		RHD, 20th, 1502-12-82-92	1
30.030		SUN VISOR ASSEMBLY (Specify Trim Set No.)		DOORS			
386897		right, 21st, 1686	1	DOOR-FRONT			
		right, 21st, 2186	1	30.3043		BRACKET - CHECK ARM	
386496		left, 21st, 1684-86	1	392117		21st, 1684	2
		left, 21st, 2184-86	1			21st, 2184	2
BODY SHEET METAL				DOORS			
CENTER PILLAR				DOOR-FRONT			
30.120		CENTER PILLAR ASSEMBLY		30.3043		BRACKET - CHECK ARM	
388688		right, 21st, 1684	1	392117		21st, 1684	2
		right, 21st, 2184	1			21st, 2184	2

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
DOOR-FRONT—Continued			
30.3438		TRIM PANEL ASSEMBLY (Specify Trim Set No.)	
251827		right, leather, 21st, 1684-86.	1
		right, leather, 21st, 2184-86.	1
251828		left, leather, 21st, 1684-86.	1
		left, leather, 21st, 2184-86.	1
30.3439		FASTENER - TRIM PANEL	
361929		21st, 1684-86.	12
		21st, 2184-86.	12
30.34395		MOULDING - TRIM PANEL TRIM	
385440		21st, 1684-86.	4
		21st, 2184-86.	4
FRONT DOOR WINDOW			
30.356		MOULDING AND DUST SEAL - WINDOW FINISHING	
385386		right, 21st, 1684-86.	1
		right, 21st, 2184-86.	1
385387		left, 21st, 1684-86.	1
		left, 21st, 2184-86.	1
30.366		GLASS - WINDOW	
388084		21st, 1684-86.	2
		21st, 2184-86.	2
30.370		FRAME - WINDOW GLASS	
388174		right, 21st, 1684-86.	1
		right, 21st, 2184-86.	1
388175		left, 21st, 1684-86.	1
		left, 21st, 2184-86.	1
30.3705		CUSHION - WINDOW FRAME TO GLASS RUBBER (Specify Length)	
376249		.080 x 1-3/8, 21st, 1684-86.	2
		.080 x 1-3/8, 21st, 2184-86.	2
30.371		GLASS AND FRAME ASSEMBLY - WINDOW	
388082		right, 21st, 1684-86.	1
		right, 21st, 2184-86.	1
388083		left, 21st, 1684-86.	1
		left, 21st, 2184-86.	1
30.382		LIFTER ASSEMBLY - WINDOW GLASS	
388086		right, 21st, 1684-86.	1
		right, 21st, 2184-86.	1
388087		left, 21st, 1684-86.	1
		left, 21st, 2184-86.	1
30.3845		CUSHION - WINDOW LIFTER TO GLASS RUBBER	
388913		21st, 1684-86.	2
		21st, 2184-86.	2

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
DOOR-REAR			
30.441		BRACKET - CHECK ARM BODY	
392117		21st, 1684.	2
		21st, 2184.	2
30.4452		FINGER GUARD TRIMMED ASSEMBLY (Specify Trim Set No.)	
251841		right, 21st, 1684-86.	1
		right, 21st, 2184-86.	1
252919		left, 21st, 1686.	1
		left, 21st, 2186.	1
7017		Screw #6 x 5/8 (50.300)	
		21st, 1684.	7
		21st, 1686.	14
		21st, 2184.	7
		21st, 2186.	14
30.46796		TRIM PANEL ASSEMBLY (Specify Trim Set No.)	
251821		right, leather, 21st, 1684-86.	1
		right, leather, 21st, 2184-86.	1
251822		left, leather, 21st, 1684-86.	1
		left, leather, 21st, 2184-86.	1
30.46797		FASTENER - TRIM PANEL	
361929		21st, 1684-86.	12
		21st, 2184-86.	12
30.468		MOULDING - TRIM PANEL TRIM	
392000		right, upper, 21st, 1684-86.	1
		right, upper, 21st, 2184-86.	1
392001		left, upper, 21st, 1684-86.	1
		left, upper, 21st, 2184-86.	1
385442		lower, 21st, 1684-86.	2
		lower, 21st, 2184-86.	2
REAR DOOR WINDOW			
30.480		MOULDING AND DUST SEAL - WINDOW FINISHING	
383864		right, 21st, 1684-86.	1
		right, 21st, 2184-86.	1
383865		left, 21st, 1684-86.	1
		left, 21st, 2184-86.	1
380425		Screw #4 x 7/8 (50.300)	
		21st, 1684-86.	2
		21st, 2184-86.	2
30.489		GLASS - WINDOW	
388154		21st, 1684-86.	2
		21st, 2184-86.	2
30.4916		FRAME - WINDOW GLASS	
388144		right, 21st, 1684-86.	1
		right, 21st, 2184-86.	1
388145		left, 21st, 1684-86.	1
		left, 21st, 2184-86.	1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
REAR DOOR WINDOW—Continued				COURTESY LIGHT—Continued			
30.4918		CUSHION - WINDOW FRAME TO GLASS RUBBER (Specify Length)		30.6119		PLATE - COURTESY LIGHT SWITCH HOLE COVER (Cont'd)	
376249		.080 x 1-3/8, 21st, 1684-86.	2	6950		Screw #6 x 3/8 (50.300)	
		.080 x 1-3/8, 21st, 2184-86.	2			21st, 1684-86.	2
						21st, 2184-86.	2
30.492		GLASS AND FRAME ASSEMBLY - WINDOW		DOME LIGHT			
388142		right, 21st, 1684-86.	1	30.622		DOME LIGHT ASSEMBLY	
		right, 21st, 2184-86.	1	375099		passenger's compartment, 21st, 1684-86.	1
388143		left, 21st, 1684-86.	1			passenger's compartment, 21st, 2184-86.	1
		left, 21st, 2184-86.	1	388667		driver's compartment, 21st, 1684.	1
8091		Screw #6 x 5/16, front (50.300).	4			driver's compartment, 21st, 2184.	1
388149		Screw #6-32 x 3/16, rear (50.002).	4	4606		Woodscrew #4 x 5/8 (50.340)	
30.500		LIFTER ASSEMBLY - WINDOW				driver's compartment, 21st, 1684.	4
388146		right, 21st, 1684-86.	1			driver's compartment, 21st, 2184.	4
		right, 21st, 2184-86.	1	30.626		SWITCH - DOME LIGHT (MANUAL OPERATED)	
388147		left, 21st, 1684-86.	1	388735		passenger's compartment, 21st, 1684-86.	1
		left, 21st, 2184-86.	1			passenger's compartment, 21st, 2184-86.	1
30.5005		CUSHION - WINDOW LIFTER TO GLASS RUBBER		369320		driver's compartment, includes roof light switch, 21st, 1684.	1
388912		21st, 1684-86.	2			driver's compartment, includes roof light switch, 21st, 2184.	1
		21st, 2184-86.	2	7999		Screw #4 x 3/4 (50.300)	
ELECTRICAL						passenger's compartment switch	
CABLES AND WIRING SETS						21st, 1684-86.	2
30.600		CABLE ASSEMBLY - ELECTRICAL BODY FEED				21st, 2184-86.	2
393560		21st, 1684-86.	1	8377		Screw #4 x 5/8 (50.340)	
		21st, 2184-86.	1			driver's compartment switch	
380559		20th, RHD, 1502-12.	1			21st, 1684.	4
						21st, 2184.	4
30.601		WIRING SET - ELECTRICAL BODY		30.629		PLATE - DOME LIGHT SWITCH	
393571		right, 21st, 1684-86.	1	377112		pillar, 21st, 1684-86.	1
		right, 21st, 2184-86.	1			pillar, 21st, 2184-86.	1
393572		left, 21st, 1684.	1	6950		Screw #6 x 3/8 (50.300).	2
		left, 21st, 2184.	1	LICENSE LIGHT			
380558		20th, RHD, 1502-12.	1	<i>For License Plate Bracket See 30.847.</i>			
		21st, RHD, 1612.	1	30.634		LICENSE LIGHT ASSEMBLY	
		21st, RHD, 2112.	1	383900		used with trunk rack, 21st, 1684-86.	1
COURTESY LIGHT						used with trunk rack, 21st, 2184-86.	1
30.6118		SWITCH - COURTESY LIGHT (DOOR OPERATED)		326933		Stud, used with trunk rack	
393517		21st, 1684-86.	3			21st, 1684-86.	2
		21st, 2184-86.	3			21st, 2184-86.	2
6950		Screw #6 x 3/8 (50.300)		6785		Lockwasher 5/16 (50.250)	
		21st, 1684-86.	6			used with trunk rack, 21st, 1684-86.	2
		21st, 2184-86.	6			used with trunk rack, 21st, 2184-86.	2
30.6119		PLATE - COURTESY LIGHT SWITCH HOLE COVER		6044		Lockwasher 5/16 (50.250)	
366521		21st, 1684-86.	1			used with trunk rack, 21st, 1684-86.	2
		21st, 2184-86.	1			used with trunk rack, 21st, 2184-86.	2
				7005		Nut 5/16-24 (50.100)	
						used with trunk rack, 21st, 1684-86.	2
						used with trunk rack, 21st, 2184-86.	2

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
LICENSE LIGHT—Continued			
30.6355		GASKET - LICENSE LIGHT	
383904		to trunk lid, packing, used with trunk rack, 21st, 1684-86.	1
		to trunk lid, packing, used with trunk rack, 21st, 2184-86.	1
327926		to trunk lid, rubber, used with trunk rack, 21st, 1684-86.	1
		to trunk lid, rubber, used with trunk rack, 21st, 2184-86.	1
30.636		BODY - LICENSE LIGHT	
383901		used with trunk rack, 21st, 1684-86.	1
		used with trunk rack, 21st, 2184-86.	1
30.643		SOCKET - LICENSE LIGHT BULB	
383906		used with trunk rack, 21st, 1684-86.	1
		used with trunk rack, 21st, 2184-86.	1
30.6435		PLATE ASSEMBLY - LICENSE LIGHT BULB SOCKET RETAINER	
383902		used with trunk rack, 21st, 1684-86.	1
		used with trunk rack, 21st, 2184-86.	1
5696		Screw #8-32 x 3/8 (50.000)	2
5225		Lockwasher #8-32 (50.220).	2
30.648		SPRING - LICENSE LIGHT BULB SOCKET	
335853		used with trunk rack, 21st, 1684-86.	1
		used with trunk rack, 21st, 2184-86.	1
30.649		CABLE - LICENSE LIGHT	
383909		used with trunk rack, 21st, 1684-86.	1
		used with trunk rack, 21st, 2184-86.	1
383383		Clip, rubber covered, used with trunk rack 21st, 1684-86.	2
		21st, 2184-86.	2
383447		Clip, steel, used with trunk rack 21st, 1684-86.	2
		21st, 2184-86.	2
30.650		GLASS - LICENSE LIGHT	
333028		used with trunk rack, 21st, 1684-86.	1
		used with trunk rack, 21st, 2184-86.	1
30.651		GASKET - LICENSE LIGHT GLASS	
326824		used with trunk rack, 21st, 1684-86.	1
		used with trunk rack, 21st, 2184-86.	1
30.6515		SPRING - LICENSE LIGHT GLASS RETAINER	
327728		used with trunk rack, 21st, 1684-86.	2
		used with trunk rack, 21st, 2184-86.	2
5310		Screw #8-32 x 1/4 (50.000)	2

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
PARTITION LIGHT			
30.6594		LIGHT AND BRACKET ASSEMBLY - PARTITION CARD CASE	
388674		21st, 1684	1
		21st, 2184	1
5347		Screw #6 x 5/8 (50.340).	1
30.65942		BRACKET - PARTITION CARD CASE LIGHT	
369369		21st, 1684	1
		21st, 2184	1
30.6595		BULB - PARTITION CARD CASE LIGHT	
56973		21st, 1684	1
		21st, 2184	1
ROOF LIGHT			
30.6669		LIGHT ASSEMBLY - ROOF (If Stenciled Specify Name)	
393668		center glass, plain, 21st, 1684-86	1
		center glass, plain, 21st, 2184-86	1
7319		Washer 1/4 (50.200).	8
354620		Washer, large (50.200)	6
5447		Lockwasher 1/4 (50.230).	8
7004		Nut 1/4-28 (50.100).	16
30.66691		BEZEL - ROOF LIGHT	
383975		21st, 1684-86.	1
		21st, 2184-86.	1
394302		Screw.	6
30.66692		BULB - ROOF LIGHT	
102590		21st, 1684-86.	4
		21st, 2184-86.	4
30.66693		GLASS - ROOF LIGHT CENTER (If Stenciled Specify Name)	
393669		plain, 21st, 1684-86	1
		plain, 21st, 2184-86	1
30.666935		GLASS - ROOF LIGHT SIDE	
383973		right, 21st, 1684-86	1
		right, 21st, 2184-86	1
383974		left, 21st, 1684-86.	1
		left, 21st, 2184-86.	1
30.66694		GASKET - ROOF LIGHT GLASS	
394305		to bezel, 21st, 1684-86.	1
		to bezel, 21st, 2184-86.	1
394306		to mounting plate, 21st, 1684-86	1
		to mounting plate, 21st, 2184-86	1
30.66695		MOUNTING PLATE ASSEMBLY - ROOF LIGHT	
394307		21st, 1684-86.	1
		21st, 2184-86.	1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
PARTITION—Continued			
30.8479		BRACKET - PARTITION TO ROOF BOW	
392149	21st, 1684		1
	21st, 2184		1
8465		Screw 1/4-20 x 5/8, to roof bow (50.003)	2
8467		Screw 1/4-28 x 1-1/4, to partition (50.003)	2
6788		Lockwasher 1/4 (50.230)	4
30.848		GRILLE - PARTITION	
365581	21st, 1684		1
	21st, 2184		1
30.8482		MOULDING - PARTITION GRILLE	
388861	21st, 1684		1
	21st, 2184		1
7998		Screw #4 x 5/8 (50.300)	10
30.8522		GLASS - PARTITION CARD CASE	
365401	21st, 1684		1
	21st, 2184		1
30.85224		STRIP - PARTITION CARD CASE GLASS RETAINER	
369157	side, 21st, 1684		2
	side, 21st, 2184		2
369156	top and bottom, 21st, 1684		2
	top and bottom, 21st, 2184		2
30.85235		LID ASSEMBLY - PARTITION CARD CASE	
388379	21st, 1684		1
	21st, 2184		1
4807		Woodscrew #6 x 1/2 (50.340)	4
30.85236		CATCH - PARTITION CARD CASE LID	
388522	21st, 1684		1
	21st, 2184		1
30.85237		STRIKER - PARTITION CARD CASE LID CATCH	
388526	21st, 1684		1
	21st, 2184		1
8486		Woodscrew #6 x 1/2 (50.340)	1
30.85238		KNOB - PARTITION CARD CASE LID	
370264	21st, 1684		1
	21st, 2184		1
388627		Screw #6-40 x 3/8 (50.000)	1
30.85239		PLATE - PARTITION CARD CASE DRIVER COMPARTMENT TRIM	
369509	21st, 1684		1
	21st, 2184		1
4810		Woodscrew #6 x 5/8 (50.340)	6
30.8525		PANEL ASSEMBLY UNTRIMMED - PARTITION CRASH PAD	
388521	21st, 1684		1
	21st, 2184		1
4922		Woodscrew #8 x 3/4, upper (50.340)	2
5347		Woodscrew #6 x 5/8, lower (50.340)	2

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
PARTITION—Continued			
30.85257		TRIM COVER ASSEMBLY - PARTITION REAR CRASH PAD (Specify Trim Set No.)	
251805	21st, 1684		1
	21st, 2184		1
30.8526		MIRROR - PARTITION	
365400	21st, 1684		1
	21st, 2184		1
3621		Woodscrew #8 x 1 (50.340)	2

PARTITION REAR WINDOW

30.855		MOULDING ASSEMBLY - PARTITION REAR WINDOW FINISHING	
383812	red, 21st, 1684		1
	red, 21st, 2184		1
383814	tan, 21st, 1684		1
	tan, 21st, 2184		1
383819	blue, 21st, 1684		1
	blue, 21st, 2184		1
383800		Clip	
	21st, 1684		1
	21st, 2184		1
6786		Screw #4 x 3/4 (50.340)	
	21st, 1684		1
	21st, 2184		1
4420		Escutcheon pin #16 x 3/4	
	21st, 1684		20
	21st, 2184		20
30.858		GLASS - PARTITION REAR WINDOW	
388235	21st, 1684		1
	21st, 2184		1
30.8592		CUSHION - PARTITION REAR WINDOW GLASS	
388531	21st, 1684		1
	21st, 2184		1

PARTITION SIDE WINDOW

30.8730		WINDOW ASSEMBLY COMPLETE - PARTITION SIDE	
388607	21st, 1684		1
	21st, 2184		1
4824		Woodscrew #10 x 7/8 (50.340)	6
30.8731		PANEL ASSEMBLY UNTRIMMED - PARTITION SIDE WINDOW FRAME LOWER EXTENSION	
392138	21st, 1684		1
	21st, 2184		1
8367		Screw #10-32 x 1/2 (50.025)	6

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
PARTITION SIDE WINDOW—Continued			
30.8732		CLAMP ASSEMBLY - PARTITION SIDE WINDOW FRONT TOGGLE	
383740	21st, 1684		1
	21st, 2184		1
8363	Screw #8-32 x 1 (50.025)		1
6803	Woodscrew #8 x 3/4 (50.340)		2
30.87321		CATCH - PARTITION SIDE WINDOW FRONT TOGGLE CLAMP	
383741	21st, 1684		1
	21st, 2184		1
8363	Screw #8-32 x 1 (50.025)		1
6803	Woodscrew #8 x 3/4 (50.340)		2
325717	Screw boss #8-32		1
30.8733		BUMPER - PARTITION SIDE WINDOW FRONT TOGGLE TO LOWER PARTITION	
392122	21st, 1684		1
	21st, 2184		1
8346	Screw #8 x 1/2 (50.300)		2
30.87331		FILLER - PARTITION SIDE WINDOW FRONT TOGGLE TO LOWER PARTITION BUMPER	
392121	21st, 1684		1
	21st, 2184		1
30.8734		SUPPORT - PARTITION SIDE WINDOW FRONT TOGGLE LOWER BUMPER	
392126	21st, 1684		1
	21st, 2184		1
4819	Woodscrew #10 x 3/4 (50.340)		2
30.87350		BRACKET ASSEMBLY - PARTITION SIDE WINDOW FRONT TOGGLE UPPER LOCK	
394530	21st, 1684		1
	21st, 2184		1
30.87351		BUMPER - PARTITION SIDE WINDOW FRONT TOGGLE UPPER LOCK BRACKET	
392164	21st, 1684		1
	21st, 2184		1
838858	Screw #10-32 x 5/16 (50.003)		2
5935	Lockwasher #10 (50.230)		2
30.8736		SUPPORT ASSEMBLY - PARTITION SIDE WINDOW FRONT TOGGLE UPPER LOCK	
394528	21st, 1684		1
	21st, 2184		1
8481	Screw 1/4-20 x 1/2 (50.025)		3
6699	Lockwasher 1/4 (50.230)		3
30.8737		GLASS - PARTITION SIDE WINDOW	
388954	sliding, 21st, 1684		1
	sliding, 21st, 2184		1
388610	stationary, 21st, 1684		1
	stationary, 21st, 2184		1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
PARTITION SIDE WINDOW—Continued			
30.87371		GLASS AND FRAME ASSEMBLY - PARTITION SIDE WINDOW SLIDING	
388609	21st, 1684		1
	21st, 2184		1
30.87372		CUSHION - PARTITION SIDE WINDOW STATIONARY GLASS TO FRAME (Specify Length)	
388994	rear, .030 x 1-1/2, 21st, 1684		1
	rear, .030 x 1-1/2, 21st, 2184		1
369062	front, .070 x 1-1/4, 21st, 1684		1
	front, .070 x 1-1/4, 21st, 2184		1
30.87373		CUSHION - PARTITION SIDE WINDOW SLIDING GLASS TO FRAME (Specify Length)	
392163	front, .110 x 1-3/4, 21st, 1684		1
	front, .110 x 1-3/4, 21st, 2184		1
369062	rear, .070 x 1-1/4, 21st, 1684		1
	rear, .070 x 1-1/4, 21st, 2184		1
30.87374		FRAME ASSEMBLY - PARTITION SIDE WINDOW GLASS	
392053	rear, 21st, 1684		1
	rear, 21st, 2184		1
388470	front, 21st, 1684		1
	front, 21st, 2184		1
388592	center, 21st, 1684		1
	center, 21st, 2184		1
8350	Screw #10-32 x 5/16, front frame (50.002)		6
30.87375		HINGE ASSEMBLY - PARTITION SIDE WINDOW GLASS FRAME REAR	
388465	21st, 1684		1
	21st, 2184		1
8353	Screw #10-32 x 5/16 (50.025)		3
30.87376		BRACKET ASSEMBLY - PARTITION SIDE WINDOW GLASS FRAME HINGE	
392225	21st, 1684		1
	21st, 2184		1
4829	Woodscrew #12 x 1 (50.340)		2
30.87377		FRAME ASSEMBLY - PARTITION SIDE WINDOW SLIDING GLASS	
388611	rear, 21st, 1684		1
	rear, 21st, 2184		1
388958	front, 21st, 1684		1
	front, 21st, 2184		1
8336	Screw #6-32 x 3/8 (50.025)		2
388966	Nut #6-32		2
30.87378		HANDLE - PARTITION SIDE WINDOW SLIDING GLASS FRAME	
383525	21st, 1684		1
	21st, 2184		1
8573	Screw #8-32 x 7/16 (50.025)		2
388968	Nut #8-32		2

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
PARTITION SIDE WINDOW—Continued				FOLDING SEAT—Continued			
30.87379		RUNWAY - PARTITION SIDE WINDOW SLIDING GLASS FRAME		30.88545		LEVERS ASSEMBLY - FOLDING SEAT CUSHION PUSH UP (Cont'd)	
394601		upper & lower, 21st, 1684	2	388457		Bolt, to seat bottom hinge	2
		upper & lower, 21st, 2184	2	330344		Spring washer	2
394602		front & rear, 21st, 1684	2	5935		Lockwasher #10 (50.230).	2
		front & rear, 21st, 2184	2	388850		Nut #10-32 (50.150).	2
SEAT				30.88546 SPRING - FOLDING SEAT CUSHION PUSH UP LEVER			
FOLDING SEAT				388561 21st, 1684 2			
				21st, 2184 2			
30.8852 BACK ASSEMBLY (UNTRIMMED) - FOLDING SEAT				30.88547 SHAFT - FOLDING SEAT CUSHION PUSH UP LEVER			
392179		21st, 1684	1	SPRING			
		21st, 2184	1	388562 21st, 1684 1			
30.88525 BACK ASSEMBLY (TRIMMED) - FOLDING SEAT				21st, 2184 1			
(Specify Trim Set No.)				30.8855 CATCH - FOLDING SEAT			
251845		21st, 1684	1	388553 21st, 1684 1			
		21st, 2184	1	21st, 2184 1			
30.8853 TRIM COVER ASSEMBLY - FOLDING SEAT BACK				383826 Pin 1			
(Specify Trim Set No.)				30.88551 DOVETAIL STUD - FOLDING SEAT CATCH			
251846		21st, 1684	1	388802 female, 21st, 1684 1			
		21st, 2184	1	female, 21st, 2184 1			
30.8854 CUSHION FRAME (UNTRIMMED) - FOLDING SEAT				388554 male, 21st, 1684 1			
388801		21st, 1684	1	male, 21st, 2184 1			
		21st, 2184	1	4307 Cotter pin 1/8 x 1-1/8 (50.240). 1			
30.88541 CUSHION ASSEMBLY (TRIMMED) - FOLDING SEAT				30.88552 SPRING - FOLDING SEAT CATCH MALE DOVETAIL			
(Specify Trim Set No.)				STUD			
251842		21st, 1684	1	388585 21st, 1684 1			
		21st, 2184	1	21st, 2184 1			
30.88542 TRIM COVER ASSEMBLY - FOLDING SEAT CUSHION				30.88553 HANDLE - FOLDING SEAT CATCH			
(Specify Trim Set No.)				388547 21st, 1684 1			
251843		21st, 1684	1	21st, 2184 1			
		21st, 2184	1	6779 Screw #10-32 x 5/8 (50.001). 1			
30.88543 BOTTOM COVER ASSEMBLY - FOLDING SEAT				30.88554 ROD - FOLDING SEAT CATCH RELEASE			
(Specify Trim Set No.)				388549 21st, 1684 1			
251844		21st, 1684	1	21st, 2184 1			
		21st, 2184	1	388821 Washer (50.200). 1			
30.88544 PIVOT BOLT - FOLDING SEAT CUSHION FRAME				4291 Cotter pin (50.240). 1			
HINGE				30.88555 PLATE - FOLDING SEAT CATCH RELEASE ROD			
388542		21st, 1684	2	BEARING			
		21st, 2184	2	392002 21st, 1684 1			
335227		Spring washer	2	21st, 2184 1			
3020		Nut 3/8-24	2	5171 Woodscrew #10 x 3/4 (50.340) 2			
30.88545 LEVERS ASSEMBLY - FOLDING SEAT CUSHION				30.88556 COVER - FOLDING SEAT CATCH ROD RELEASE ROD			
PUSH UP				388550 21st, 1684 1			
388556		21st, 1684	1	21st, 2184 1			
		21st, 2184	1	8077 Screw #8 x 1/2 (50.300). 9			
30.88557 SPRING - FOLDING SEAT CATCH RELEASE ROD				388552 21st, 1684 1			
				21st, 2184 1			

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
FOLDING SEAT—Continued				FRONT SEAT—Continued			
30.88558		HINGE - FOLDING SEAT CENTER PILLAR		30.8985		TRIM COVER ASSEMBLY - REAR OF FRONT SEAT BACK (Specify Trim Set No.)	
388568		lower, 21st, 1684.	1	252912		21st, 1686	1
		lower, 21st, 2184.	1			21st, 2186	1
388569		upper, 21st, 1684.	1				
		upper, 21st, 2184.	1	30.8987		TRIM COVER ASSEMBLY - REAR OF FRONT SEAT BACK FOOT REST (Specify Trim Set No.)	
7235		Lockwasher 5/16 (50.230)	4	252923		21st, 1686	1
388825		Nut 5/16-24 (50.150)	4			21st, 2186	1
30.8857		SUPPORT ASSEMBLY - FOLDING SEAT PARTITION		30.900		SPRING - BACK CUSHION	
388543		21st, 1684	1	386534		driver's seat, 21st, 1684.	1
		21st, 2184	1			driver's seat, 21st, 2184.	1
224251		Screw boss 5/16-24	3	30.9001		FRAME ASSEMBLY (TRIMMED) - BOTTOM (Specify Trim Set No.)	
8306		Screw 5/16-24 x 1-1/2, for screw boss (50.002)	3	981844		cloth, RHD, 20th, 1505-15.	1
8304		Screw 5/16-24 x 1 (50.002)	3	981798		cloth, RHD, 20th, 1585-88-95-98.	1
6527		Lockwasher 5/16 (50.220)	6	981801		leather, RHD, 20th, 1505-15.	1
7005		Nut 5/16-24 (50.100)	3	981800		leather, RHD, 20th, 1585-88-95-98.	1
30.8858		SCUFF PLATE - FOLDING SEAT PARTITION SUPPORT		252929		cloth, RHD, 21st, 1615	1
388602		front, 21st, 1684.	1			cloth, RHD, 21st, 2115	1
		front, 21st, 2184.	1	252930		cloth, RHD, 21st, 1685-95.	1
388603		rear, 21st, 1684	1			cloth, RHD, 21st, 2185-95.	1
		rear, 21st, 2184	1	252931		leather, RHD, 21st, 1615	1
8308		Screw #6-32 x 5/16 (50.002).	4			leather, RHD, 21st, 2115	1
				252932		leather, RHD, 21st, 1685-95.	1
						leather, RHD, 21st, 2185-95.	1
FRONT SEAT				30.9005		CUSHION (TRIMMED ASSEMBLY) - (Specify Trim Set No.)	
30.8981		FRAME ASSEMBLY (TRIMMED) - FRONT SEAT BACK (Specify Trim Set No.)		251806		driver's seat, 21st, 1684.	1
252920		21st, 1686	1			driver's seat, 21st, 2184.	1
		21st, 2186	1	252911		21st, 1686	1
252925		cloth, RHD, 21st, 1612	1			21st, 2186	1
		cloth, RHD, 21st, 2112	1	30.9006		TRIM COVER ASSEMBLY - CUSHION (Specify Trim Set No.)	
252926		cloth, RHD, 21st, 1682-92.	1	251807		driver's seat, 21st, 1684.	1
		cloth, RHD, 21st, 2182-92.	1			driver's seat, 21st, 2184.	1
252927		leather, RHD, 21st, 1612	1	252914		21st, 1686	1
		leather, RHD, 21st, 2112	1			21st, 2186	1
252928		leather, RHD, 21st, 1682-92.	1	30.9008		SUPPORT - CUSHION PAD	
		leather, RHD, 21st, 2182-92.	1	386529		driver's seat, 21st, 1684.	1
30.89815		BACK CUSHION ASSEMBLY (TRIMMED) - FRONT SEAT				driver's seat, 21st, 2184.	1
251810		21st, 1684	1	30.908		SPRING - CUSHION	
		21st, 2184	1	386533		driver's seat, 21st, 1684.	1
252910		21st, 1686	1			driver's seat, 21st, 2184.	1
		21st, 2186	1	386909		21st, 1686	1
30.8982		TRIM COVER ASSEMBLY - BACK CUSHION (Specify Trim Set No.)				21st, 2186	1
251811		driver's seat, 21st, 1684.	1	30.927		HANDLE - ADJUSTING	
		driver's seat, 21st, 2184.	1	372538		RHD, 20th, 1502-12-82-92	1
252913		21st, 1686	1			RHD, 21st, 1612-82-92.	1
		21st, 2186	1			RHD, 21st, 2112-82-92.	1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
FRONT SEAT—Continued			
30.927		HANDLE - ADJUSTING (Cont'd)	
	363145	RHD, 20th, 1505-15-85-88-95-98	1
		RHD, 21st, 1615-85-95.	1
		RHD, 21st, 2115-85-95.	1
30.92723		LEVER AND BRACKET ASSEMBLY - ADJUSTING HANDLE	
	380162	RHD, 20th, 1502-12-82-92	1
		RHD, 21st, 1612-82-92.	1
		RHD, 21st, 2112-82-92.	1
30.92729		SHAFT, BRACKET, AND RELAY ASSEMBLY - ADJUSTING HANDLE	
	374626	RHD, 21st, 1615-85-95.	1
		RHD, 21st, 2115-85-95.	1
30.9277		SPRING - ADJUSTING HANDLE RELAY	
	374623	RHD, 20th, 1505-15-85-88-95-98	1
		RHD, 21st, 1615-85-95.	1
		RHD, 21st, 2115-85-95.	1
30.930		TRACK ASSEMBLY - ADJUSTING	
	380159	RHD, right, 20th, 1502-12-82-92.	1
		RHD, right, 21st, 1612-82-92	1
		RHD, right, 21st, 2112-82-92	1
	374132	RHD, right, 20th, 1505-15-85-88-95-98.	1
		RHD, right, 21st, 1615-85-95	1
		RHD, right, 21st, 2115-85-95	1
	380160	RHD, left, 20th, 1502-12-82-92	1
		RHD, left, 21st, 1612-82-92.	1
		RHD, left, 21st, 2112-82-92.	1
	374133	RHD, left, 20th, 1505-15-85-88-95-98	1
		RHD, left, 21st, 1615-85-95.	1
		RHD, left, 21st, 2115-85-95.	1
30.9384		MOULDING - TRIM	
	392488	back, 21st, 1686	1
		back, 21st, 2186	1
	383882	side, 21st, 1686	2
		side, 21st, 2186	2
REAR SEAT			
30.9401		CUSHION ASSEMBLY (TRIMMED) - BACK (Specify Trim Set No.)	
	251839	21st, 1684-86.	1
		21st, 2184-86.	1
30.9402		TRIM COVER ASSEMBLY - BACK CUSHION (Specify Trim Set No.)	
	251840	21st, 1684-86.	1
		21st, 2184-86.	1
30.941		SPRING - CUSHION	
	386532	21st, 1684-86.	1
		21st, 2184-86.	1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
REAR SEAT—Continued			
30.9412		CUSHION ASSEMBLY (TRIMMED) - (Specify Trim Set No.)	
	251833	21st, 1684-86.	1
		21st, 2184-86.	1
30.9413		TRIM COVER ASSEMBLY - CUSHION (Specify Trim Set No.)	
	251835	21st, 1684-86.	1
		21st, 2184-86.	1
30.9475		ARM REST ASSEMBLY (TRIMMED) - SIDE (Specify Trim Set No.)	
	251849	right, 21st, 1684-86	1
		right, 21st, 2184-86	1
	251850	left, 21st, 1684-86.	1
		left, 21st, 2184-86.	1
30.9476		TRIM COVER ASSEMBLY - SIDE ARM REST (Specify Trim Set No.)	
	251991	right, 21st, 1684-86	1
		right, 21st, 2184-86	1
	251992	left, 21st, 1684-86.	1
		left, 21st, 2184-86.	1
30.9478		MOULDING - TRIM	
	386629	21st, 1684-86.	1
		21st, 2184-86.	1
TRUNK			
31.1503		LINING - TRUNK COMPARTMENT FRONT	
	386438	21st, 1684-86.	1
		21st, 2184-86.	1
31.157		TRUNK LID ASSEMBLY	
	372159	used without trunk rack, 21st, 1684-86	1
		used without trunk rack, 21st, 2184-86	1
	392335	used with trunk rack, 21st, 1684-86.	1
		used with trunk rack, 21st, 2184-86.	1
31.1875		BRACKET - LID LOCK STRIKER SUPPORT	
	388447	used with trunk screen, 21st, 1684	1
		used with trunk screen, 21st, 2184	1
TRUNK RACK			
31.205		TRUNK RACK ASSEMBLY	
	387573	21st, 1684-86.	1
		21st, 2184-86.	1
	387564	Screw.	2
	387566	Spacer	2
	335227	Spring washer.	2
	6902	Nut 3/8-24 (50.120).	2

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR	CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
TRUNK RACK—Continued				WINDOW REAR—Continued			
31.206		SPACER - RACK BAR		31.353		GLASS (Cont'd)	
387580		21st, 1684-86.	6	388846		Bolt 1/4-28 x 11/16, to ninge	
		21st, 2184-86.	6			21st, 1684-86.	4
						21st, 2184-86.	4
31.207		BOLT - RACK BAR SPACER		388883		Nut 1/4-28, to hinge bolt	
387583		21st, 1684-86.	2			21st, 1684-86.	4
		21st, 2184-86.	2			21st, 2184-86.	4
6902		Nut 3/8-24 (50.120).	2	31.3531		HINGE ASSEMBLY - GLASS	
31.208		BRACE - RACK		388598		right, 21st, 1684-86	1
387569		21st, 1684-86.	2			right, 21st, 2184-86	1
		21st, 2184-86.	2	388599		left, 21st, 1684-86.	1
367021		Screw.	2			left, 21st, 2184-86.	1
333761		Washer, fiber.	2	383775		Screw #10-32 x 9/16, to operating motor.	2
335227		Spring washer.	2	6779		Screw #10-32 x 5/8, to roof (50.001)	4
6902		Nut 3/8-24 (50.120).	2	383796		Washer 3/16.	4
31.209		BRACKET - RACK		394508		Cup washer	4
387504		right, 21st, 1684-86	1	31.3571		SPACER - GLASS RUBBER	
		right, 21st, 2184-86	1	388844		21st, 1684-86.	4
387503		left, 21st, 1684-86.	1			21st, 2184-86.	4
		left, 21st, 2184-86.	1	31.3572		WASHER - GLASS RUBBER	
7841		Screw 3/8-24 x 1-1/4 (50.003).	4	388845		21st, 1684-86.	4
5506		Lockwasher 3/8 (50.220).	4			21st, 2184-86.	4
7006		Nut 3/8-24 (50.100).	4	31.358		WEATHERSTRIP - GLASS	
31.210		KNOB - RACK CLAMPING		388626		used with ventilating window, 21st, 1684-86	1
367022		21st, 1684-86.	2			used with ventilating window, 21st, 2184-86	1
		21st, 2184-86.	2	31.368		MOTOR - OPERATING	
31.211		SPRING - RACK CLAMPING KNOB		392035		21st, 1684-86.	1
367234		21st, 1684-86.	2			21st, 2184-86.	1
		21st, 2184-86.	2	383765		Screw #10-32 x 5/8	1
367023		Retaining ring	2	5500		Lockwasher #10 (50.220).	1
367235		Retaining washer	2	7003		Nut #10-32 (50.100).	1
31.212		PIVOT PIN - RACK		31.369		SPRING - OPERATING MOTOR	
387565		21st, 1684-86.	2	383760		21st, 1684-86.	2
		21st, 2184-86.	2			21st, 2184-86.	2
387566		Spacer	2	31.3695		SWITCH - OPERATING MOTOR	
31.213		STRAP - RACK		383938		21st, 1684-86.	1
367095		21st, 1684-86.	1			21st, 2184-86.	1
		21st, 2184-86.	1	31.370		TUBE - OPERATING MOTOR VACUUM	
31.214		PLATE - RACK STRAP RETAINING		392107		141" long, 21st, 1684-86	1
367217		21st, 1684-86.	1			141" long, 21st, 2184-86	1
		21st, 2184-86.	1	387875		4" long, manifold end, 21st, 1684-86	1
228151		Rivet 3/16 x 5/8 (50.425).	2			4" long, manifold end, 21st, 2184-86	1
				383758		Clip	11
				333343		Screw #10-24 x 3/8	11
				377453		Connection, manifold end	1
				6261		Nut, manifold end.	1
				31.371		GROMMET - OPERATING MOTOR VACUUM TUBE	
				197876		21st, 1684-86.	1
						21st, 2184-86.	1
				31.372		HOSE - OPERATING MOTOR VACUUM TUBE	
				383682		14" long, 21st, 1684-86.	1
						14" long, 21st, 2184-86.	1
				387876		8" long, manifold end, 21st, 1684-86	1
						8" long, manifold end, 21st, 2184-86	1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
WINDSHIELD			
31.394		MOULDING - DIVISION FINISHING INSIDE	
	383558	Plug 5/16-24, mirror hole, 21st, 1684.	1
		Plug 5/16-24, mirror hole, 21st, 2184.	1
TRIM			
31.414		CENTER PILLAR TRIM ASSEMBLY (Specify Trim Set No.)	
	251851	right, 21st, 1684.	1
		right, 21st, 2184.	1
	975076	right, 21st, 1686.	1
		right, 21st, 2186.	1
	251852	left, 21st, 1684.	1
		left, 21st, 2184.	1
	975077	left, 21st, 1686.	1
		left, 21st, 2186.	1
31.417		CARPET ASSEMBLY - FLOOR FRONT (Specify Trim Set No.)	
	952107	RHD, leather trim, 20th, 1502-05-12-15-82-85-88-92-95-98	1
31.430		MAT - FLOOR FRONT RUBBER	
	388928	21st, 1684	1
		21st, 2184	1
	392495	21st, 1686	1
		21st, 2186	1
	350429	RHD, cloth trim, 20th, 1502-05-12-15-82-85-88-92-95-98	1
	386720	RHD, 21st, 1612-15-72-75-82-85-92-95	1
		RHD, 21st, 2112-15-72-75-82-85-92-95	1
31.431		MAT - FLOOR REAR RUBBER	
	388810	21st, 1684	1
		21st, 2184	1
	392497	21st, 1686	1
		21st, 2186	1
31.4314		MAT - FRONT SEAT SIDE SILL RUBBER	
	388811	left, 21st, 1684	1
		left, 21st, 2184	1
	392498	21st, 1686	2
		21st, 2186	2
31.4315		MOULDING - FLOOR MAT JOINT	
	392108	21st, 1684	1
		21st, 2184	1
	8451	Screw #10 x 1/2 (50.300)	10
31.4398		FORMICA TRIM PANELS	
	386501	door front, bottom right, 21st, 1684-86.	1
		door front, bottom right, 21st, 2184-86.	1
	386502	door front, bottom left, 21st, 1684-86	1
		door front, bottom left, 21st, 2184-86	1
	386508	door front, top right, 21st, 1684-86	1
		door front, top right, 21st, 2184-86	1

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
TRIM-Continued			
31.4398		FORMICA TRIM PANELS (Cont'd)	
	386509	door front, top left, 21st, 1684-86.	1
		door front, top left, 21st, 2184-86.	1
	386503	door rear, bottom right, 21st, 1684-86	1
		door rear, bottom right, 21st, 2184-86	1
	386504	door rear, bottom left, 21st, 1684-86.	1
		door rear, bottom left, 21st, 2184-86.	1
	386510	door rear, top right, 21st, 1684-86.	1
		door rear, top right, 21st, 2184-86.	1
	386511	door rear, top left, 21st, 1684-86	1
		door rear, top left, 21st, 2184-86	1
	386512	folding seat, back center, 21st, 1684.	1
		folding seat, back center, 21st, 2184.	1
	386893	front seat, back center, 21st, 1686.	1
		front seat, back center, 21st, 2186.	1
	383874	front seat, side lower right front, 21st, 1686	1
		front seat, side lower right front, 21st, 2186	1
	383876	front seat, side lower right rear, 21st, 1686	1
		front seat, side lower right rear, 21st, 2186	1
	383875	front seat, side lower left front, 21st, 1686	1
		front seat, side lower left front, 21st, 2186	1
	383877	front seat, side lower left rear, 21st, 1686	1
		front seat, side lower left rear, 21st, 2186	1
	383880	partition, rear, 21st, 1684.	1
		partition, rear, 21st, 2184.	1
	383879	partition, side lower, 21st, 1684.	1
		partition, side lower, 21st, 2184.	1
	386725	partition, rear lower outer, 21st, 1684.	1
		partition, rear lower outer, 21st, 2184.	1
	386853	partition, rear lower driver side front, 21st, 1684	1
		partition, rear lower driver side front, 21st, 2184	1
	386506	rear seat, right, 21st, 1684-86.	1
		rear seat, right, 21st, 2184-86.	1
	386507	rear seat, left, 21st, 1684-86	1
		rear seat, left, 21st, 2184-86	1
	7017	Screw #6 x 1/2 (50.300)	
		door front, bottom panel, 21st, 1684-86.	18
		door front, bottom panel, 21st, 2184-86.	18
		door front, top panel, 21st, 1684-86	6
		door front, top panel, 21st, 2184-86	6
		door rear, bottom panel, 21st, 1684-86	12
		door rear, bottom panel, 21st, 2184-86	12
		door rear, top panel, 21st, 1684-86.	10

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
TRIM—Continued			
31.4398		FORMICA TRIM PANELS (Cont'd)	
		door rear, top panel, 21st, 2184-86.	10
		front seat, back panel, 21st, 1686	13
		front seat, back panel, 21st, 2186	13
		front seat, side panel, 21st, 1686	18
		front seat, side panel, 21st, 2186	18
		partition, rear lower panel, 21st, 1684	8
		partition, rear lower panel, 21st, 2184	8
		partition, rear lower outer panel, 21st, 1684	6
		partition, rear lower outer panel, 21st, 2184	6
7586		Screw #6 x 3/4 (50.300)	
		folding seat, back panel, 21st, 1684	26
		folding seat, back panel, 21st, 2184	26
		rear seat panel, 21st, 1684-86	6
		rear seat panel, 21st, 2184-86	6
8385		Screw #6-32 x 3/8 (50.300)	
		folding seat, back panel inner, 21st, 1684	3
		folding seat, back panel inner, 21st, 2184	3
8370		Screw #6-32 x 5/16 (50.300)	
		folding seat, back panel outer, 21st, 1684	2
		folding seat, back panel outer, 21st, 2184	2
8280		Screw #6 x 1, (50.300)	
		to rear seat panel, 21st, 1684-86.	8
		to rear seat panel, 21st, 2184-86.	8
8263		Ferrule #6	
		door front, bottom panel, 21st, 1684-86.	18
		door front, bottom panel, 21st, 2184-86.	18
		door front, top panel, 21st, 1684-86	6
		door front, top panel, 21st, 2184-86	6
		door rear, bottom panel, 21st, 1684-86 12	12
		door rear, bottom panel, 21st, 2184-86 12	12
		door rear, top panel, 21st, 1684-86.	10
		door rear, top panel, 21st, 2184-86.	10
		front seat, back panel, 21st, 1686	13
		front seat, back panel, 21st, 2186	13
		front seat, side panel, 21st, 1686	18
		front seat, side panel, 21st, 2186	18
		partition, rear lower panel, 21st, 1684 8	8
		partition, rear lower panel, 21st, 2184 8	8
		partition, rear lower outer panel, 21st, 1684	4
		partition, rear lower outer panel, 21st, 2184	4
		rear seat, panel, 21st, 1684-86.	14
		rear seat, panel, 21st, 2184-86.	14
		folding seat back panel, 21st, 1684.	26
		folding seat back panel, 21st, 2184.	26

CODE NO.	PART NO.	DESCRIPTION AND MODELS	PER CAR
TRIM—Continued			
31.4398		FORMICA TRIM PANELS (Cont'd)	
394506		Clip, partition rear	
		21st, 1684	3
		21st, 2184	3
31.4589		DOOR ASSEMBLY (TRIMMED) - HEADLINING ROOF LIGHT ACCESS	
252816		21st, 1684-86.	1
		21st, 2184-86.	1
7402		Screw #4 x 5/8 (50.340).	1
31.459		TRIM PANEL ASSEMBLY - COWL SIDE (Specify Trim Set No.)	
251819		right, 21st, 1684-86	1
		right, 21st, 2184-86	1
251820		left, 21st, 1684-86.	1
		left, 21st, 2184-86.	1
31.4609		TOP ASSEMBLY - UNDER REAR WINDOW PACKAGE TRAY (Specify Trim Set No.)	
386855		red leather trim, 21st, 1684-86.	1
		red leather trim, 21st, 2184-86.	1
386856		tan leather trim, 21st, 1684-86.	1
		tan leather trim, 21st, 2184-86.	1
386857		blue leather trim, 21st, 1684-86	1
		blue leather trim, 21st, 2184-86	1
31.46093		WHEELHOUSE PANEL TRIMMED ASSEMBLY - REAR QUARTER (Specify Trim Set No.)	
252702		right, 21st, 1684-86	1
		right, 21st, 2184-86	1
252703		left, 21st, 1684-86.	1
		left, 21st, 2184-86.	1

BULK TRIM STOCK

31.481		LEATHER - IMITATION (Specify Trim Set No.)	
386499		headlining material, set No. 12, 14, 19, 112, 114 and 119, 21st, 1684-86.	x
		headlining material, set No. 12, 14, 19, 112, 114 and 119, 21st, 2184-86.	x

PackardInfo.com