

16.006-16.012

TOOLS

16.006-16.012

•16.006

TOOL CONTAINER AND TOOLS

395981	2213.....	INCLUDES WHEEL WRENCH AND SPARK PLUG WRENCH	1
419542	2313.....	INCLUDES WHEEL WRENCH AND SPARK PLUG WRENCH	1
317620	2201-02-06-22-32-33; 2301-02-06-32-33; 2401-02-06; 2501-02-06-31; 2601-02-06- 11-26-31-33	EXPORT, INCLUDES SIX OPEN END WRENCHES, PLIERS, MONKEY WRENCH, TWO SCREW DRIVERS, SPARK PLUG WRENCH, AND HAMMER	1

16.0066

TOOL & JACK SET COMPLETE

419541	2201-02-06-11-22-26-32-33; 2301-02-06- 32-33	INCLUDES JACK WITH BASE AND HANDLE (WHEEL WRENCH), SPARK PLUG WRENCH AND CONTAINER	1
403475	2201-02-06-11-20-22-26-32-33-40; 2301- 02-06-32-33	EXPORT, INCLUDES JACK WITH BASE AND HANDLE (WHEEL WRENCH), TOOL CONTAINER AND TOOLS, GREASE GUN, AND TIRE PUMP	1
433143	2401-02-06; 2501-02-06-31; 2601-02-06- 11-26-31-33	INCLUDES JACK WITH BASE AND HANDLE (WHEEL WRENCH) SPARK PLUG WRENCH AND CONTAINER	1
426675	2401-02-06; 2501-02-06-31; 2601-02-06- 11-26-31-33	EXPORT, INCLUDES JACK WITH BASE AND HANDLE (WHEEL WRENCH) TOOL CONTAINER AND TOOLS, GREASE GUN, AND TIRE PUMP	1
446871	5400-01-02-06-11-26-31-33.....	INCLUDES JACK WITH BASE AND HANDLE (WHEEL WRENCH) AND CONTAINER	1

16.011

WRENCH-SPARK PLUG & FENDER SHROUD

419323	2401-02-06; 2501-02-06-31; 2601-02-06- 11-26-31-33; 5400-01-02-06-11-26-31-33	1
--------	--	-------	---

16.012

WRENCH-JACK HANDLE & WHEEL

426070	ALL 22ND; 23RD; 24TH; 25TH; 26TH; 54TH..	1
--------	--	-------	---

PackardInfo.com